





**Advanced Test Equipment Rentals**  
**www.atecorp.com 800-404-ATEC (2832)**



**Agilent 53181A**  
**225 MHz Frequency Counter**

**Operating Guide**



**Agilent Technologies**

Manual Part Number 53181-90001  
Printed in Malaysia

## NOTES

---

# Agilent 53181A Operating Guide

This guide describes how to use the Agilent 53181A 225 MHz Frequency Counter.

---

Agilent 53181A 225 MHz Frequency  
Counter

©Copyright 1994 - 2003  
Agilent Technologies, Inc.

All Rights Reserved. Reproduction, adaptation, or translations without prior written permission is prohibited, except as allowed under the copyright laws.

Printed: November 2003

Printed in Malaysia

**Manual part number  
53181-90001**

### Certification and Warranty

#### Certification

Agilent Technologies certifies that this product met its published specification at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (formerly National Bureau of Standards), to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

#### Warranty

Agilent warrants Agilent hardware, accessories and supplies against defects in materials and workmanship for a period of one year from date of shipment. If Agilent receives notice of such defects during the warranty period, Agilent will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or like-new.

Agilent warrants that Agilent software will not fail to execute its programming instructions, for the period specified above, due to defects in material and workmanship when properly installed and used. If Agilent receives notice of such defects during the warranty period, Agilent will replace software media which does not execute its programming instructions due to such defects.

#### Safety Considerations

##### General

This product and related documentation must be reviewed for familiarization with this safety markings and instructions before operation.

#### Before Cleaning

Disconnect the product from operating power before cleaning.

#### Warning Symbols That May Be Used In This Book



Instruction manual symbol; the product will be marked with this symbol when it is necessary for the user to refer to the instruction manual.



Indicates hazardous voltages.



Indicates earth (ground) terminal.



or



Indicates terminal is connected to chassis when such connection is not apparent.



Indicates Alternating current.



Indicates Direct current.

#### Safety Considerations (contd)

**WARNING** \_\_\_\_\_  
**BODILY INJURY OR DEATH MAY RESULT FROM FAILURE TO HEED A WARNING. DO NOT PROCEED BEYOND A WARNING UNTIL THE INDICATED CONDITIONS ARE FULLY UNDERSTOOD AND MET.**

**CAUTION** \_\_\_\_\_  
Damage to equipment, or incorrect measurement data, may result from failure to heed a caution. Do not proceed beyond a *CAUTION* until the indicated conditions are fully understood and met.

#### Safety Earth Ground

An uninterruptible safety earth ground must be maintained from the mains power source to the product's ground circuitry.

**WARNING** \_\_\_\_\_  
**WHEN MEASURING POWER LINE SIGNALS, BE EXTREMELY CAREFUL AND ALWAYS USE A STEP-DOWN ISOLATION TRANSFORMER WHICH OUTPUT IS COMPATIBLE WITH THE INPUT MEASUREMENT CAPABILITIES OF THIS PRODUCT. THIS PRODUCT'S FRONT AND REAR PANELS ARE TYPICALLY AT EARTH GROUND. *THUS, NEVER TRY TO MEASURE AC POWER LINE SIGNALS WITHOUT AN ISOLATION TRANSFORMER.***

---

### Warranty (contd)

Agilent does not warrant that the operation of Agilent products will be uninterrupted or error free. If Agilent is unable, within a reasonable time, to repair or replace any product to a condition as warranted, customer will be entitled to a refund of the purchase price upon prompt return of the product.

Agilent products may contain remanufactured parts equivalent to new in performance or may have been subjected to incidental use.

The warranty period begins on the date of delivery or on the date of installation if installed by Agilent. If customer schedules or delays Agilent installation more than 30 days after delivery, warranty begins on the 31st day from delivery.

Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by Agilent, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

**TO THE EXTENT ALLOWED BY LOCAL LAW, THE ABOVE WARRANTIES ARE EXCLUSIVE AND NO OTHER WARRANTY OR CONDITION, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED AND AGILENT SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE.**

Agilent will be liable for damage to tangible property per incident up to the greater of \$300,000 or the actual amount paid for the product that is the subject of the claim, and for damages for bodily injury or death, to the extent that all such damages are determined by a court of competent jurisdiction to have been directly caused by a defective Agilent product.

**TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE CUSTOMER'S SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL AGILENT OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE.**

For consumer transactions in Australia and New Zealand: the warranty terms contained in this statement, except to the extent lawfully permitted, do not exclude, restrict or modify and are in addition to the mandatory statutory rights applicable to the sale of this product to you.

### Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales and Service Office.

### Safety Considerations (contd)

#### WARNING

**INSTRUCTIONS FOR ADJUSTMENTS WHILE COVERS ARE REMOVED AND FOR SERVICING ARE FOR USE BY SERVICE-TRAINED PERSONNEL ONLY. TO AVOID DANGEROUS ELECTRIC SHOCK, DO NOT PERFORM SUCH ADJUSTMENTS OR SERVICING UNLESS QUALIFIED TO DO SO.**

#### WARNING

**ANY INTERRUPTION OF THE PROTECTIVE GROUNDING CONDUCTOR (INSIDE OR OUTSIDE THE PRODUCT'S CIRCUITRY) OR DISCONNECTING THE PROTECTIVE EARTH TERMINAL WILL CAUSE A POTENTIAL SHOCK HAZARD THAT COULD RESULT IN PERSONAL INJURY. (GROUNDING ONE CONDUCTOR OF A TWO CONDUCTOR OUTLET IS NOT SUFFICIENT PROTECTION.)**

Whenever it is likely that the protection has been impaired, the instrument must be made inoperative and be secured against any unintended operation.

If this instrument is to be energized via an autotransformer (for voltage reduction) make sure the common terminal is connected to the earthed pole terminal (neutral) of the power source.

Instructions for adjustments while covers are removed and for servicing are for use by trained-personnel only. To avoid dangerous electric shock, do not perform such adjustments or servicing unless qualified to do so.

For continued protection against fire, replace the line fuse(s) of the same current rating and type (for example, normal blow, time delay). Do not use repaired fuses or short circuited fuseholders.

### Acoustic Noise Emissions

LpA<47 dB at operator position, at normal operation, tested per EN 27779. All data are the results from type test.

### Geräuschemission

LpA<47 dB am Arbeitsplatz, normaler Betrieb, geprüft nach EN 27779.  
Die Angaben beruhen auf Ergebnissen von Typenprüfungen.



Agilent Technologies

# DECLARATION OF CONFORMITY

According to ISO/IEC Guide 22 and CEN/CENELEC EN 45014



**Manufacturer's Name:** Agilent Technologies, Incorporated  
**Manufacturer's Address:** Santa Clara Site  
 5301 Stevens Creek Blvd  
 Santa Clara, California 95051

## Declares, that the product

**Product Name:** Universal Counter Frequency Counter  
**Model Number:** 53131A, 53132A 53181A  
**Product Options:** *This declaration covers all options of the above product.*

## Conforms with the following European Directives:

*The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC (including 93/68/EEC) and carries the CE Marking accordingly.*

EMC	Standard	Limit
	IEC 61326-1:1997+A1:1998 / EN 61326-1:1997+A1:1998 CISPR 11:1990 / EN 55011:1991 IEC 61000-4-2:1995+A1:1998 / EN 61000-4-2:1995 IEC 61000-4-3:1995 / EN 61000-4-3:1995 IEC 61000-4-4:1995 / EN 61000-4-4:1995 IEC 61000-4-5:1995 / EN 61000-4-5:1995 IEC 61000-4-6:1996 / EN 61000-4-6:1996 IEC 61000-4-11:1994 / EN 61000-4-11:1994	Group 1 Class A <sup>[1]</sup> 4kV CD, 8kV AD 3 V/m, 80-1000 MHz 0.5kV signal lines, 1kV power lines 0.5 kV line-line, 1 kV line-ground 3V, 0.15-80 MHz 1 cycle, 100%
	Canada: ICES-001:1998 Australia/New Zealand: AS/NZS 2064.1	
<b>Safety</b>	IEC 61010-1:1990+A1:1992+A2:1995 / EN 61010-1:1993+A2:1995 Canada: CSA C22.2 No. 1010.1:1992	

## Supplemental Information:

<sup>[1]</sup> *The product was tested in a typical configuration with Agilent Technologies test systems.*

July 31, 2001

Date

Art Nanawa, Product Regulations Manager

---

# Contents

## In This Guide

<b>Contents and Organization</b>	<b>xii</b>
<b>Related Documents</b>	<b>xiii</b>
<b>Types of Service Available if Your Instrument Fails</b>	<b>xiv</b>
Standard Repair Services (Worldwide)	xiv
Express Repair/Performance Calibration Service (USA Only)	xiv
Repair Instrument Yourself	xiv
<b>Repackaging for Shipment</b>	<b>xv</b>
<b>Description of the 225 MHz Frequency Counter</b>	<b>xvi</b>
<b>Options</b>	<b>xvii</b>
Hardware	xvii
Support	xvii
<b>Accessories Supplied and Available</b>	<b>xviii</b>
Accessories Supplied	xviii
Accessories Available	xviii
<b>Agilent 53181A Quick Reference Guide</b>	<b>xix</b>

## 1 Getting Started

<b>The Front Panel at a Glance</b>	<b>1-2</b>
<b>The Front Panel Indicators at a Glance</b>	<b>1-3</b>
<b>The Front Panel Indicators at a Glance (Cont.)</b>	<b>1-4</b>
<b>The Front Panel Menus at a Glance</b>	<b>1-5</b>
<b>The Front Panel Menus at a Glance (Cont.)</b>	<b>1-6</b>
<b>The Front Panel Menus at a Glance (Cont.)</b>	<b>1-7</b>
<b>The Display Annunciators at a Glance</b>	<b>1-8</b>
<b>The Display Special Characters at a Glance</b>	<b>1-9</b>
The Underscore Placeholder	1-9
The Asterisk Placeholder	1-9

- The Limit Test Graph Characters at a Glance 1-10**
- The Rear Panel at a Glance 1-11**
- Making Measurements 1-12**
  - To Measure Frequency 1-14
  - To Select Input Coupling and Impedance 1-15
    - Selecting Input Coupling 1-15
    - Selecting Input Impedance 1-15
  - To Set Input Channel Trigger Level/Sensitivity 1-16
    - Changing Trigger Mode 1-16
    - Modifying Input Trigger Level 1-17
    - Selecting Input Trigger Slope 1-18
    - Selecting Input Sensitivity 1-18
    - Starting the Measurement 1-19
  - To Select Scale and Offset 1-19
    - Entering the Scale Value 1-19
    - Entering the Offset Value 1-20
    - Displaying the Math Results 1-21
    - Disabling Math 1-22
  - To Set Limits of Measurements 1-23
    - Setting the Upper Limit 1-24
    - Setting the Lower Limit 1-25
    - Setting the Counter to Flag and Stop Measuring On Out-of-Limit Measurements 1-27
    - Setting the Counter to Flag On Limits But Continue Measuring 1-28
    - Disabling Limit Testing 1-28
    - Disabling Math 1-29
  - To Perform Statistics on Measurements 1-29
    - Selecting the Type of Statistics (Stats) 1-29
    - Computing Stats on Filtered Data Only 1-31
    - Displaying Stats After Filtering Data of Input Signal 1-33
    - Disabling Stats and Math 1-34
  - To Control Measurement 1-35



## 2 Operating Your Frequency Counter

### **Introduction 2-2**

Chapter Summary 2-2

Where to Find Some Key Working Examples 2-3

### **How this Counter Works for You 2-4**

### **Summary of the Measurement Sequence 2-5**

### **Using the Measurement Control Keys (Run and Stop/Single) 2-6**

Overview of the Measurement Control Keys 2-6

To Use the Measurement Control Keys 2-7

### **Using Entry/Select (Arrow) Keys 2-9**

To Use During Numeric Entry 2-9

To Use When Sequencing Through the Other Meas and Recall Menus 2-9

To Use During State Changing (ON/OFF, LO/MED/HI, etc.) 2-10

To Use on Prompted Help Messages (MATH HELP: NO/YES, PRT HELP: NO/YES) 2-10

### **Using the MEASURE Menu Keys 2-11**

Overview of the MEASURE Menus 2-11

To Measure Frequency 2-12

To Measure Frequency Ratio (Optional) 2-13

To Measure Period 2-13

To Measure Positive/Negative Volt Peaks 2-14

### **Using the Gate & External Arm Menu Key 2-15**

Overview of Gate/External Arming Functions 2-15

TIME Arming 2-15

AUTO Arming 2-15

EXTERNAL Arming 2-15

DIGITS Arming 2-16

To Use the Gate and External Arm 2-17

Example Procedure for Gate and External Arm 2-17

## Contents

Example Procedure for Changing the Number of Digits of Resolution Displayed for More Precise Measurements	2-19
<b>Using the MATH Menu Keys</b>	<b>2-21</b>
Overview of Scale/Offset Math Menu	2-21
To Use the Scale/Offset Math Menu	2-22
Example Procedure for Scale Function	2-22
Example Procedure for Offset Function	2-23
Example Procedure for Turning Off Math Mode	2-25
Example Procedure for Set Reference Function—Offset From the Last Measurement Value ( <i>Seeing Digits Not Visible on the 12-Digit Display</i> )	2-25
Overview of Statistics (Stats) Menu	2-26
To Use the Stats Menu for Automatic and Continuous Statistical Analysis	2-27
Example Procedure for Computing Stats	2-27
Example Procedure for Easy Viewing of Stats	2-28
Example Procedure for Filtering Data (Using Limits) During Stats	2-29
Example Procedure for Configuring SINGLE to Initiate N Measurements	2-30
Example Procedure for Turning Off Stats Mode	2-30
<b>Using the LIMITS Menu Keys</b>	<b>2-31</b>
Overview of Limits Menus	2-31
To Set and Use Automatic Limit Testing	2-32
Limits Testing Example 1—Flag and Stop Measuring On Limits	2-32
Limits Testing Example 2—Flag On Limits but Continue Measuring	2-34
Limits Testing Example 3—Use Analog Graph Display While Adjusting/Aligning Input Signal	2-34
Limits Testing Example 4—Selecting Filtering Conditions of Stats Computation	2-36

## Contents

Limits Testing Example 5—Sending the Limit-Detect Output to the RS-232 Serial Port	2-38
<b>Using the DISPLAY Digits Keys</b>	<b>2-39</b>
Overview of the DISPLAY Digits Keys	2-39
To Use the DISPLAY Digits Keys	2-40
<b>Using CHANNEL 1 Input Conditioning Keys</b>	<b>2-41</b>
Overview of Trigger/Sensitivity Menu	2-41
To Use the Trigger/Sensitivity Key to Adjust Counter's Trigger Voltage and Sensitivity Levels	2-44
Overview of Input Conditioning Toggle Keys	2-47
<b>Using the Save and Recall Menus</b>	<b>2-48</b>
Overview of Save and Recall Functions	2-48
To Use the Save Function	2-49
To Use the Recall Function	2-50
To Unsave a Measurement Setup	2-51
<b>Using the Print Menu</b>	<b>2-52</b>
Overview of the Print Menu	2-52
To Use the Print Menu	2-52
<b>Using the Utility Menu</b>	<b>2-53</b>
Overview of the Utility Menu	2-53
To Set the GPIB Address	2-54
Selecting Operating Mode (Talk/Listen, Talk-Only)	2-54
Setting the GPIB Address	2-54
To Choose the Timebase Source	2-55
To Run the Self-Test Routines	2-56
Overview of the Self-Test Routines	2-56
Example Procedure for Running the Self Test	2-57
To Configure the RS-232 Serial Port for Printing	2-58
Setting the Hardware Pacing	2-58
Setting the Baud Rate	2-59
Setting the Parity	2-59
Setting the Software Pace	2-59

## Contents

- To Configure the RS-232 Serial Port for Sending Limit-Detect Output 2-60
- To Select the Numerical Convention for the Display 2-61
- To Connect the Counter to a Serial Printer via the RS-232 Port 2-61
- To Connect the Counter to a Printer via GPIB 2-62
- To Select the GPIB Talk-Only Mode for Printing 2-62

### **Front Panel Display Messages 2-63**

- Measurement Result Displays 2-63
- Power-Up/Self Test Messages 2-64
- Menu Messages 2-65
- GPIB Messages 2-67

### **Preset Values After Power-up and \*RST 2-68**

- Preset Values for Functions Accessible Via Front Panel or GPIB 2-68
- Preset Values for Functions Accessible Via GPIB Only 2-72

### **Common Questions 2-74**

- Why is Stats result not available yet? 2-74
- Why won't printer work? 2-74
- Why did Counter stop measuring? 2-74
- Why did Counter go to its default state after I set up my RS-232 port? 2-74
- Counter's numeric display does not follow the numerical convention for my country. 2-74

## **3 Specifications**

### **Introduction 3-2**

- Instrument Inputs 3-2
- Instrument Inputs (Continued) 3-3
- Time Base 3-4
- Measurement Specifications 3-5
- Measurement Specifications (Continued) 3-6
- Measurement Specifications (Continued) 3-12
- Measurement Definitions 3-15

## Contents

Measurement Arming and Processing	3-16
General Information	3-17

## **Index**

## Contents

---

# In This Guide

This book is the operating guide for the Agilent 53181A 225 MHz Frequency Counter. It consists of a table of contents, this preface, a quick reference guide, three chapters, and an index.

This preface contains the following information:

- Contents and Organization page xii
- Related Documents page xiii
- Types of Service Available if Your Instrument Fails page xiv
- Repackaging for Shipment page xv
- Description of the 225 MHz Frequency Counter page xvi
- Options page xvii
- Accessories Supplied and Available page xviii

---

## Contents and Organization

The **Table of Contents** lists the beginning of each chapter in the guide, helping you locate information.

The **Preface** introduces you to the operating guide, the Frequency Counter, and provides general information about the Counter.

The **Quick Reference Guide** consists of a Menu Tree (tear-out sheet) that serves as a tool to trigger your memory or get you quickly reacquainted with the instrument, and Menu Roadmaps that illustrate how to navigate through the menus. It is located after this preface.

Chapter 1, “**Getting Started**,” is a quick start guide that gives you a brief overview of the Counter’s keys, indicators, menus, display, and connectors. Last, a graphical procedure for performing a complete measurement is provided.

Chapter 2, “**Operating Your Frequency Counter**,” is an operator’s reference. You are given an overview of each group of front-panel keys, operating functions, and menus followed by a series of exercises that guide you through the operation of the Counter.

Chapter 3, “**Specifications**,” lists the specifications and characteristics of the Counter.

The **Index** helps you find items easily by arranging information in a sequence different from that found in the Table of Contents, disclosing relationships among items.



---

## Related Documents

For more information on counters refer to the following Series 200 Application Notes:

- *Fundamentals of Electronic Frequency Counters* Application Note 200—Agilent part number 02-5952-7506.
- *Understanding Frequency Counter Specifications* Application Note 200-4—Agilent part number 02-5952-7522.

## Types of Service Available if Your Instrument Fails

If your Counter fails within one year of original purchase, Agilent will repair it free of charge. If your instrument fails after your 1-year warranty expires, Agilent will repair it, or you can repair it yourself by ordering the service guide.

There are three types of repair services:

- Standard repair service—if downtime is not critical.
- Express Repair/Performance Calibration Service—if downtime is critical.
- Use the Assembly-Level Service Guide and repair the unit yourself.

### **Standard Repair Services (Worldwide)**

Contact your nearest Agilent Technologies Service Center. They will arrange to have your Counter repaired.

### **Express Repair/Performance Calibration Service (USA Only)**

If downtime is critical, you can receive your repaired Counter via overnight shipment. Just call 1-800-403-0801 and ask for *Express Repair/Performance Calibration Service*. When your Counter is repaired, it will be returned via overnight shipment.

### **Repair Instrument Yourself**

If your Counter 1-year warranty has expired and you choose to repair the instrument yourself or would like more details on self-test and calibration, use the procedures in the Assembly-Level Service Guide.

## Repackaging for Shipment

For the Express Repair/Performance Calibration Service described above, return your failed Counter to the designated Agilent Service Center, using the shipping carton of the instrument. Agilent will notify you when your failed instrument has been received.

If the instrument is to be shipped to Agilent for service or repair, be sure you do the following:

- Attach a tag to the instrument identifying the owner and indicating the required service or repair. Include the instrument model number and full serial number.
- Place the instrument in its original container (if available) with appropriate packaging material.
- Secure the container with strong tape or metal bands.

If the original shipping container is not available, place your unit in a container which will ensure at least 4 inches of compressible packaging material around all sides of the unit. Use static free packaging materials to avoid additional damage to your unit.

*Agilent Technologies suggests that you always insure shipments.*

---

## Description of the 225 MHz Frequency Counter

The Agilent 53181A is a frequency counter capable of measuring frequencies to 225 MHz on Channel 1. Depending on which optional Channel 2 the counter contains, this capability is extended to 1.5 GHz (Option 015), 3.0 GHz (Option 030), 5.0 GHz (Option 050) or 12.5 GHz (Option 124). The Agilent 53181A has a frequency resolution of 10 digits in one second.

The Agilent 53181A provides users with a GPIB measuring speed of up to 200 measurements per second, and is suitable for bench-top and ATE operation.

The Agilent 53181A basic measurement functions include Frequency, Period, Peak Voltage, and Frequency Ratio (if Channel 2 is installed).

The Agilent 53181A includes additional measurement functions and features that are designed specifically for manufacturing and service applications:

- 1, 5, 10 MHz external reference capability—to match customer's house standard,
- optional ultra high, high, or medium stability oven oscillators for high accuracy needs and lengthened calibration cycles,
- external gating,
- full math and statistics,
- automatic limit testing,
- analog display mode limit testing, and
- SCPI programming capability.

Programmable control is performed via an GPIB. The GPIB and a talk-only RS-232C serial port are standard for the Agilent 53181A. The serial port is for printing measured and analyzed data on serial printers, or for outputting an out-of-limit signal.

---

## Options

The options available for the Agilent 53181A 225 MHz Frequency Counter are listed following this paragraph. Specifications for the options are listed in Chapter 3, “Specifications.” If you’ve purchased an option with the initial order, it will be installed at the factory and ready for operation at delivery. Refer to the “Retrofitting Options” chapter in the Assembly-Level Service Guide for instructions on field installation of the options.

---

**NOTE**

---

The “0s” and “1s” in the following option numbers are numeric characters (that is, they are not letters).

### Hardware

- Medium Stability Oven Timebase, Option 001
- DC Power Input, Option 002
- High Stability Oven Timebase, Option 010
- Ultra High Stability Oven Timebase, Option 012
- 1.5 GHz RF Input Channel (Channel 2), Option 015
- 3.0 GHz RF Input Channel (Channel 2), Option 030
- 5.0 GHz RF Input Channel (Channel 2), Option 050
- 12.4 GHz RF Input Channel (Channel 2), Option 124
- Rear Terminals\*, Option 060
- Rack Mount Kit, Option 1CM

### Support

- 5-year Return to Agilent for Repair, Option W50
- 5-year Return to Agilent for Calibration, Option W52

---

\* Channel 1 will have both front and rear terminals. Option 015 and Option 030 Channel 2 will have a rear terminal only. Option 050 and Option 124 Channel 2 will have a front terminal only.

---

## Accessories Supplied and Available

### **Accessories Supplied**

- Power cord, 2.3 meters

### **Accessories Available**

- Agilent 34161A Accessory Pouch
- Agilent 34131A Transit Case
- Printer RS-232 Interface cables, Agilent 24542G or Agilent 24542H
- GPIB cables, Agilent 10833A/B/C/D

---

## Agilent 53181A Quick Reference Guide

The Quick Reference Guide is designed for experienced users of the Agilent 53181A Frequency Counter. It is intended to be used as a tool to trigger your memory. If you are using the Agilent 53181A for the first time, Agilent recommends that you at least read Chapter 1, “Getting Started,” in the Operating Guide first.


The Quick Reference Guide follows this page, and consists of the following items:

- A Menu Tree which may be torn out of the guide for external use (pages 1 and 2).
- Menu Roadmaps which illustrate via key-press sequences how to navigate through the menus under the menu keys (pages 3 through 10). Key-press sequences are provided for the following menu keys:
  - **Freq Ch1**
  - **Freq Ch2**
  - **Other Meas**
  - **Gate & ExtArm**
  - **Uppr & Lower**
  - **Limit Modes**
  - **Scale & Offset**
  - **Stats**
  - **Trigger/Sensitivity**


## Preface





# Agilent 53181A Frequency Counter





# Agilent 53181A Frequency Counter






# Agilent 53181A Frequency Counter




# Agilent 53181A Frequency Counter





# Agilent 53181A Frequency Counter





# Agilent 53181A Frequency Counter



# Agilent 53181A Frequency Counter



# Agilent 53181A Frequency Counter






---

1

---

Getting Started

## The Front Panel at a Glance








- |                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>1 Measurement function menu keys</li> <li>2 Limits menu keys</li> <li>3 Math menu keys</li> <li>4 Sign (+ or -) selection toggle key</li> <li>5 Data Entry/Select (or arrow) keys</li> <li>6 Enter numeric data (terminate) key. Also traverses a menu and exits at the end of a menu.</li> <li>7 Channel 2 optional RF input</li> </ul> | <ul style="list-style-type: none"> <li>8 Utility menu key (Hold during power-up to access Utility functions.)</li> <li>9 Recall, Save and Print menu keys</li> <li>10 Gate and External Arm menu key</li> <li>11 Measurement control keys</li> <li>12 Display Digits keys</li> <li>13 Channel 1 Trigger/Sensitivity menu key and input conditioning keys</li> </ul> |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

**NOTE**





It is normal operation for the fan in the Counter to continue to run after the Counter is placed in Standby mode. Power to the timebase is continuous to maintain long term measurement reliability, and the fan helps maintain timebase temperature stability.

## The Front Panel Indicators at a Glance


There are eight different groups of indicators or LEDs. They are listed and described in the following table.

Indicators	Description of the Indicators
	<p>When the indicator for the <b>Freq Ch 1</b> or <b>Freq Ch 2</b> keys is lit, it indicates that the Frequency function is enabled for the corresponding input channel.</p> <p>When the indicator for the <b>Other Meas</b> key is lit, it simultaneously indicates that the key's menu and its menu item (for example, PERIOD 1) is enabled.</p>
	<p>When these indicators are lit, the key's "enable" menu item (that is, Limit Modes/<b>LIM TEST</b>, Scale &amp; Offset/<b>MATH</b>, Stats/<b>STATS</b>, and Save &amp; Print/<b>PRINT</b>) is enabled.</p>
	<p>When this indicator is lit, it indicates that auto-triggering is enabled.</p>
	<p>When this indicator flashes, it indicates that the arrow keys can be used to modify or enter data.</p> <p>The <b>Enter</b> key is used to enter numeric values or parameters. It can also be used to traverse through a menu. Pressing the <b>Enter</b> key at the end or bottom of a menu will cause the Counter to exit the menu and return to the measurement mode.</p>
	<p>When one of these indicators is lit, it indicates that the Run or Single function is enabled.</p>

**The Front Panel Indicators at a Glance (Cont.)**

Indicators	Description of the Indicators
	<p>When this indicator flashes, it indicates that the Counter is triggering on the input signal. If the input signal is too high, this indicator remains ON. If the input signal is too low, this indicator is OFF.</p>
	<p>When one of these indicators is lit, it indicates that the adjacent choice (that is, 50Ω DC, X10, or 100kHz Filter) is enabled or active. Note that when these indicators are not lit, then the other choice (that is, 1MΩ AC, X1, or no filter) is active.</p>
<p>Remote   Error (Flashing)</p> <p>SRQ </p>	<p>A lit Remote indicator indicates that the Counter is in remote mode (<b>Note:</b> In the remote mode, the Save &amp; Print key becomes the <b>Local</b> key.)</p> <p>If (while in remote) an error occurs, the Remote indicator will flash. The indicator will continue flashing until the controller has read or cleared the error queue, or until the front panel returns to local mode.</p> <p>An unlit Remote indicator indicates that the Counter is in local mode.</p> <p>The SRQ indicator indicates that the Counter has requested service from the controller. The SRQ indicator will remain lit until the controller has recognized the service request and serial polled the Counter, or taken specific action to cancel the request (for example, *CLS command).</p>


## The Front Panel Menus at a Glance



<sup>1</sup> These menu items appear only if your Counter contains the optional 1.5 GHz, 3.0 GHz, or 5.0 GHz RF Input (Channel 2).

<sup>2</sup> Refer to Chapter 2 in this guide for details on the Gate & ExtArm menu.

**The Front Panel Menus at a Glance (Cont.)**




- <sup>3</sup> This appears when nothing can be recalled.
- <sup>4</sup> Only registers which can be recalled will appear in this menu.
- <sup>5</sup> This menu item only appears if an instrument setup has been saved.

## The Front Panel Menus at a Glance (Cont.)


**NOTE**

Turn power off, press and hold Recall (**Utility**) key, then press **POWER** key to access this menu.



<sup>6</sup> These menu items appear only if TEST LOOP is OFF.


## The Display Annunciators at a Glance



Annunciator	Indication
<b>Period</b>	Counter is set to measure Period.
<b>Freq</b>	Counter is set to measure Frequency.
<b>Ch 1</b>	Counter's channel 1 is selected to measure an input signal.
<b>Ch 2</b>	Counter's channel 2 is selected to measure an input signal.
<b>Limit</b>	Counter is limit testing and the current measurement exceeds the user-entered limits.
<b>ExtRef</b>	Counter is set to use the signal connected at rear panel Ref In connector as the timebase (TIMEBAS: EXT); or Counter is set to automatically (TIMEBAS: AUTO) select the timebase and has chosen the signal connected at the rear panel Ref In connector.
<b>Hz</b>	The displayed data is in units of Hertz.
<b>M</b>	The prefix for the units of the displayed data is mega ( $10^6$ ).
<b>μ</b>	The prefix for the units of the displayed data is micro ( $10^{-6}$ ).
<b>s</b>	The displayed data is in units of seconds.
<b>Gate</b>	The gate is open. Before a measurement cycle starts, this annunciator is OFF, indicating the gate is closed. During a measurement cycle, the annunciator is ON, indicating the gate is open.




## The Display Special Characters at a Glance



### The Underscore Placeholder


Special Character	Description
—	A placeholder that indicates the digit has been blanked using the <b>Display Digits</b> keys.



### The Asterisk Placeholder


Special Character	Description
*	A placeholder that indicates this digit is not significant because of the measurement resolution. (The appearance of this asterisk is determined by the Counter; thus, these cannot be removed by the <b>Display Digits</b> keys.)

## The Limit Test Graph Characters at a Glance



Special Character	Description
:	The colons represent the lower and upper limits.
*	The asterisk represents the last measurement.

## The Rear Panel at a Glance



- |                                                                                  |                                              |
|----------------------------------------------------------------------------------|----------------------------------------------|
| 1 Rear-panel input connectors (optional)                                         | 6 10 MHz Output connector                    |
| 2 Power module (Senses incoming voltage and automatically selects proper setup.) | 7 GPIB (IEEE-488.1) interface connector      |
| 3 Fan                                                                            | 8 Oscillator Adjust potentiometer            |
| 4 External Arm input connector                                                   | 9 RS-232 Interface or Limit Output connector |
| 5 External Reference Input connector                                             |                                              |

**NOTE**

It is normal operation for the fan in the Counter to continue to run after the Counter is placed in Standby mode. Power to the timebase is continuous to maintain long term measurement reliability, and the fan helps maintain timebase temperature stability.

---

## Making Measurements

One of the first things you will want to do with your Counter is to become acquainted with its front panel. Therefore, we have written the procedures in this section to familiarize you with some of its controls. The following procedures are provided:


- First you are shown how to turn on the Counter and measure the frequency of a signal applied to the Counter's input channels.
- Second, you are shown how to use the input coupling, impedance, and trigger/sensitivity keys to set the input conditions of Channel 1 to match the signal being measured.
- Third, you are shown how to scale and offset the measurement result.
- Fourth, you are shown how to set upper and lower limits for measurements.
- Fifth, you are shown how to enable the Counter to compute statistics (such as standard deviation) and display statistics of measurements.
- Last, you are shown how to use the Run and Stop/Single keys to control measurements.

The order of the procedures in this chapter is the recommended order for making measurements with this Counter.

Chapter 1 Getting Started  
**Making Measurements**

Study and refer to the following legend, as needed, to understand the meaning of the icons which are used throughout this chapter.


**Legend**




- |                                          |                            |                              |
|------------------------------------------|----------------------------|------------------------------|
| <b>1</b> Press key one time and release  | <b>5</b> Result            | <b>9</b> Indicator off       |
| <b>2</b> Press key two times and release | <b>6</b> Auto operation    | <b>10</b> Indicator on       |
| <b>3</b> Repeated key presses            | <b>7</b> Connect signal    | <b>11</b> Indicator flashing |
| <b>4</b> Press and hold                  | <b>8</b> Disconnect signal |                              |

Chapter 1 Getting Started  
Making Measurements

To Measure Frequency



Connect (for demonstration purposes) the Counter's rear-panel **10 MHz Out** signal to CHANNEL 1 input as shown in the illustrated procedure, below.




The Counter will automatically display the measured frequency of the input signal.

## Chapter 1 Getting Started



### Making Measurements

If you need or want to change CHANNEL 1's coupling, impedance, and triggering conditions to match the input signal you are trying to measure, the next procedures "To Select Input Coupling and Impedance" and "To Set Input Channel Trigger Level/Sensitivity" demonstrate this. Perform these procedures whether or not you want to customize the Counter's input conditions to measure your signal; doing this will help you become familiar with the **DC/AC**, **50Ω/1MΩ** and **Trigger/Sensitivity** keys.




### To Select Input Coupling and Impedance

#### Selecting Input Coupling




Channel 1's input coupling is now set to dc.

If you want to change the coupling back to the default ac coupling, perform the following step.



#### Selecting Input Impedance



Channel 1's input impedance is now set to 50Ω


---

**NOTE**

The "arrow" keys can also be used to toggle the state of toggle keys (DC/AC, 50Ω/1MΩ etc.) as indicated by the flashing indicator within the arrow keys. However, for simplicity in this procedure, use the corresponding toggle key to change states.


Chapter 1 Getting Started  
**Making Measurements**

If you want to change the input impedance back to the default 1 M $\Omega$  impedance, perform the following step.





**To Set Input Channel Trigger Level/Sensitivity**

*Changing Trigger Mode*




Press any one of these arrow keys to toggle to the next state of Auto Trigger.







Chapter 1 Getting Started  
Making Measurements

*Modifying Input Trigger Level*






The leftmost "0" digit in the LEVEL display is highlighted, indicating that if you press the d key once the displayed value will increase to 1.000 volt as shown in the following step.



Channel 1's trigger level is now set to +1V.


To set the trigger level to -2V, perform the following steps.



Channel 1's trigger level is now set to -2V.


Chapter 1 Getting Started  
Making Measurements

*Selecting Input Trigger Slope*



Refer to the sub-section titled “To Use the Trigger/Sensitivity Key to Adjust Counter’s Trigger Voltage and Sensitivity Levels” in Chapter 2 for more information about trigger slope, if needed.


*Selecting Input Sensitivity*



Refer to the sub-section titled “To Use the Trigger/Sensitivity Key to Adjust Counter’s Trigger Voltage and Sensitivity Levels” in Chapter 2 for more information about sensitivity, if needed.

Chapter 1 Getting Started  
**Making Measurements**

*Starting the Measurement*



The **Run** key initiates repetitive measurements, and is described in the section titled “To Control Measurement” at the end of this chapter.



**To Select Scale and Offset**

The **Scale & Offset** key allows for multiplication and addition, respectively, of the measurement by user-specified constants. Modification of the displayed measurement by these Math operations is represented by the following equation:


$$(\text{Measurement} \times \text{Scale}) + \text{Offset} = \text{Displayed Results}$$

The Scale and Offset Math operations can be used, for example, to subtract systematic errors or display the percentage difference between signals.

*Entering the Scale Value*




To demonstrate the Scale Math operation, set Scale to 10 as shown in the following steps.



Chapter 1 Getting Started  
**Making Measurements**

Press and hold the **d** key until the value of Scale is 10 as shown in the following step.




**NOTE**

**BE SURE to press the *Enter* key to enter the value of 10.**


The Scale is now set to 10, and MATH has been enabled. The Scale & Offset indicator is now lit to show that MATH is enabled. Since MATH is enabled, the results are being scaled and offset.

***Entering the Offset Value***

To demonstrate the Offset Math operation, set the Offset to 1 MHz as shown in the following steps.




At this point, pressing the **s** key will cause the Counter to display the full display of the Offset value as shown in the following step.




## Chapter 1 Getting Started

### Making Measurements

Press the **s** key six more times to cause the Counter to display your entry in Mega units as shown in the following step.



The leftmost “0” digit in the OFFSet display is highlighted, indicating that if you press **d** key once the displayed value will increase to 1 Mega (that is, 1E6) as shown in the following step.




---

**NOTE**

**BE SURE to press the *Enter* key to enter the 1 Mega value.**

The Offset is now set to 1 Mega.


#### *Displaying the Math Results*




The Counter displays the modified measurement results, which are based on the scale and offset values that you selected in the previous steps. (For more details and real applications of the Math Scale and Offset operations, refer to the appropriate section in Chapter2, “Operating Your Frequency Counter.”)

Chapter 1 Getting Started  
Making Measurements

*Disabling Math*



Note that the **Scale & Offset** key indicator is now off.




**NOTE**

**DO NOT** cycle **POWER** because you will need to use these Scale and Offset values in the following procedure “To Set Limits of Measurements.” Continue to the following procedure.

Chapter 1 Getting Started  
**Making Measurements**

**To Set Limits of Measurements**

To demonstrate how Math and Limits work together, use the Scale (10) and Offset (1 Mega) values selected in the previous procedure “To Select Scale and Offset.” Enable Math by performing the following steps.





The result of this Math operation is a measurement of 101 MHz.

$$(\text{Measurement} \times \text{Scale}) + \text{Offset} = \text{Result}$$


$$(10 \text{ MHz} \times 10) + 1 \text{ Mega} = 101 \text{ Mega}$$

Now, set the upper limit to 102 Mega and the lower limit to 100 Mega by performing the following procedures. (Figure 1-1 and Figure 1-2 illustrate the limits settings.)


Chapter 1 Getting Started  
Making Measurements






*Setting the Upper Limit*



Press the *s* key nine times to cause the Counter to display your entry in hundreds of Mega units as shown in the following step.



The leftmost “0” digit in the UPPR display is highlighted as shown above, indicating that each press of the *d* key will increase the displayed value.




**NOTE**

**BE SURE** to press the *Enter* key to enter the 102 Mega value.




Chapter 1 Getting Started  
**Making Measurements**




- 1 102 Mega Upper Limit
- 2 101 Mega Scale/Offset Measurement

**Figure 1-1. 102 Mega Upper Limit Setting**

*Setting the Lower Limit*



Press the arrow keys as shown in the following steps to set the lower limit value. Press the *s* key nine times to cause the Counter to display your entry in hundreds of Mega units as shown in the following step.




**NOTE**

**BE SURE to press the *Enter* key to enter the 100 Mega value.**

Chapter 1 Getting Started  
**Making Measurements**


Limits should now be set as shown in Figure 1-2.



- 1 102 Mega Upper Limit
- 2 101 Mega Scale/Offset Measurement
- 3 100 Mega Lower Limit

**Figure 1-2. 100 Mega Lower and 102 Mega Upper Limits Settings**

Figure 1-3 represents what transpired during this Math and Limits procedure.




- 1 Raw Measurements
- 2 Math
- 3 Limits
- 4 Measurements (Scale/Offset Results) within Limits

**Figure 1-3. Math and Limits Results**

Chapter 1 Getting Started  
**Making Measurements**

***Setting the Counter to Flag and Stop Measuring On Out-of-Limit Measurements***

If you want the Counter to stop measuring when the signal exceeds the limits (102 to 100 Mega) that you entered in the previous procedure, perform the following steps to select the STOP choice in the ON FAIL display. (Note that ON FAIL: GO ON is the default state after power-up.)




The current modified measurement of the input signal applied to CHANNEL 1 is displayed.

Since the Counter is now in the stop-on-fail mode, the **Limit** annunciator in the display will light and the Counter will stop making measurements when a measurement exceeds the limits you set. The measurement result that exceeded the entered limits will be held on the display for observation.

Chapter 1 Getting Started  
**Making Measurements**

***Setting the Counter to Flag On Limits But Continue Measuring***


Perform the following steps to select the GO ON choice in the ON FAIL display if you want the Counter to continue measuring even though an measurement result exceeds the limits previously entered.



The current modified measurement of the input signal applied to CHANNEL 1 is displayed.

Since the Counter is now in the go-on-fail mode, the **Limit** annunciator in the display will light each time a measurement exceeds the limits you set. However, the Counter will continue to make measurements.



***Disabling Limit Testing***



The Counter is now making measurements without limit testing.

Chapter 1 Getting Started  
**Making Measurements**

*Disabling Math*




The Counter is now making measurements without the scale/offset values calculated into the measurements.

**To Perform Statistics on Measurements**


*Selecting the Type of Statistics (Stats)*

Suppose you want the Counter to compute and display the **standard deviation** of the current input data (which is the 10 MHz signal applied to CHANNEL 1). Also, you want the Counter to make 20 measurements before it computes the standard deviation. Perform the following steps.



Chapter 1 Getting Started  
Making Measurements

Updating the SHOW configuration caused Stats to be enabled. The Stats indicator is now lit.





**NOTE**

**BE SURE** to press the *Enter* key to enter the value of 20.

Chapter 1 Getting Started  
**Making Measurements**


The Counter is now set to make statistics based on 20 measurements.



In this case, the displayed standard deviation value is computed on all measurements of the 10 MHz signal since no limits were set.

***Computing Stats on Filtered Data Only***

A special feature of the Counter allows you to use the upper and lower limits to filter data before statistical processing or computation as shown in Figure 1-4.




- |                           |                                        |
|---------------------------|----------------------------------------|
| <b>1</b> Raw Measurements | <b>3</b> Filtered data (USE: IN LIMIT) |
| <b>2</b> Limits           | <b>4</b> Statistics                    |


**Figure 1-4. Filtering Data Before Statistical Computation**

Chapter 1 Getting Started  
Making Measurements

Perform the following steps to select the IN LIMIT choice in the USE display if you want the Counter to compute statistics on only frequency measurements within the limits you set.



Since the Limits were set to 100 Mega and 102 Mega values that are based on a scale of 10 and offset of 1 Mega, you must re-enable Math now to get the measurements to be within the limits. Perform the following steps.






## Chapter 1 Getting Started

### Making Measurements

#### *Displaying Stats After Filtering Data of Input Signal*

Let's assume you have set the upper and lower limits for the input signal, and selected the IN LIMIT (filtering) choice. Now, perform the following steps to display the standard deviation of the filtered measurements. (Note that the first step in the following procedure is optional since you should have already set Stats to show standard deviation at the beginning of this Stats procedure. But, you may want to perform the step anyway to verify that the Counter is displaying the standard deviation of the measurement.)




The standard deviation value shown in the previous illustration is for demonstration purposes. The statistic is computed using only those measurements which fell within the limits you set.

(For more details on the Stats and Limits functions, refer to the appropriate sections in Chapter 2, "Operating Your Frequency Counter.")

Now, disable Math and Stats as shown in the following procedure.

Chapter 1 Getting Started  
Making Measurements


*Disabling Stats and Math*



The Counter is now making and displaying normal measurements (that is, the Counter is not showing statistics or scale/offset results).

Chapter 1 Getting Started  
**Making Measurements**

**To Control Measurement**



Use these two keys to control the measurement of the Counter. The **Run** key provides repetitive measurements, whereas the **Stop/Single** key allows you to make one measurement.

With the 10 MHz signal still connected to CHANNEL 1, perform the following steps so you can better understand the Run and Stop/Single operations.




The Counter is now making repetitive measurements (continuously making “live” measurements).



The Counter stopped making measurements. The **Gate** annunciator is not lit. Hence, pressing the **Stop/Single** key while the Counter is making measurements (in **Run**) causes the Counter to stop after the measurement in progress is completed. If you press the **Stop/Single** key again while the Counter is stopped, the Counter will make a single measurement and then stop—the **Gate** annunciator will light one time, momentarily.


If you press the **Stop/Single** key while the Counter is stopped and when the Stats menu item ON SINGLE is set to N, the Counter will make N measurements and then stop. This enables a set of statistics to be computed.

While the Counter is still stopped, perform the following step.



The Counter is making repetitive measurements again.

Chapter 1 Getting Started  
**Making Measurements**



---

# Operating Your Frequency Counter

Operator's Reference

---

## Introduction

This is the operator's reference chapter which contains information and procedures for the front-panel keys, operating functions, and menus of the Agilent 53181A 225 MHz Frequency Counter.


### Chapter Summary

- How this Counter Works for You page 2-4
- Summary of the Measurement Sequence page 2-5
- Using the Measurement Control Keys (Run and Stop/Single) page 2-6
- Using Entry/Select (Arrow) Keys page 2-9
- Using the MEASURE Menu Keys page 2-11
- Using the Gate & External Arm Menu Key page 2-15
- Using the MATH Menu Keys page 2-21
- Using the LIMITS Menu Keys page 2-31
- Using the DISPLAY Digits Keys page 2-39
- Using CHANNEL 1 Input Conditioning Keys page 2-41
- Using the Save and Recall Menus page 2-48
- Using the Print Menu page 2-52
- Using the Utility Menu page 2-53
- Front Panel Display Messages page 2-63
- Preset Values After Power-up and \*RST page 2-68
- Common Questions page 2-74

**Introduction**

**Where to Find Some Key Working Examples**

- Example Procedure for Gate and External Arm page 2-17
- Example Procedure for Changing the Number of Digits of Resolution Displayed for More Precise Measurements page 2-19
- Example Procedure for Scale Function page 2-22
- Example Procedure for Offset Function page 2-23
- Example Procedure for Set Reference Function—Offset From the Last Measurement Value (Seeing Digits Not Visible on the 12-Digit Display) page 2-25
- Example Procedure for Computing Stats page 2-27
- Limits Testing Example 1—Flag and Stop Measuring On Limits page 2-32
- Limits Testing Example 2—Flag On Limits but Continue Measuring page 2-34
- Limits Testing Example 3—Use Analog Graph Display While Adjusting/Aligning Input Signal page 2-34
- Limits Testing Example 4—Selecting Filtering Conditions of Stats Computation page 2-36
- Limits Testing Example 5—Sending the Limit-Detect Output to the RS-232 Serial Port spage 2-38



---

## How this Counter Works for You

The following text lists some of the key things the Counter does for you.

- The Counter presets the menus to default states and values at power-up (refer to Table 2-6 for a detailed list of the preset values). Cycling the **POWER** key presets the Counter.
- The Counter's Utility menu allows you to select such things as timebase source, GPIB configuration, and RS-232 serial port configuration. After your selections, the Counter automatically stores all these selections in *non-volatile* memory (**except the timebase source**); thus, these settings (except timebase source) *will not* change when power has been off or after a remote interface reset.
- The Counter automatically displays measurement(s) in a couple of seconds after you select a measurement function (e.g., Period).
- The Counter accepts your numeric entry for a menu item after you press the **Enter** key. *You MUST press the Enter key to complete numeric entry.*
- The Counter automatically enables Limits when you enter a numeric value for upper and/or lower limits, or update any menu item in the Limit Modes menu.
- The Counter automatically enables Math after you enter a numeric value for scale and offset.
- The Counter performs Statistical analyses for you, and will enable Stats when you update any item in the Stats menu.
- The Counter automatically disables Limits, Math, and Stats when you select another measurement function.
- The Counter saves measurement setup(s).
- The Counter instantly recalls the measurement setup you want to use.
- The Counter prints out your measurement and analysis data.



## Summary of the Measurement Sequence

Use **Utility** menu to:

- choose the timebase source.
- configure the GPIB if you intend to operate the Counter remotely.
- set RS-232 serial port if you intend for the Counter to perform printing and/or limit-detecting.

Use **MEASURE** menu keys to select the measurement function.

Use **CHANNEL 1** keys to set up input conditioning.

Use **Gate & ExtArm** key to:

- set the gate time and resolution.
- set arming.

Use **Scale & Offset** key to set up math operations.

Use **Uppr & Lower** key to set limits.

Use **Limit Modes** key to set up limit testing.

Use **Stats** key to set up statistics and limit filtering.

Use **Save & Print** key to enable or disable printing.

Use **Run** and **Stop/Single** keys to control measurements.

## Using the Measurement Control Keys (Run and Stop/Single)

### Overview of the Measurement Control Keys



Two measurement control keys are provided on the Counter: **Run** and **Stop/Single**. In general, the **Run** key provides repetitive measurements while the **Stop/Single** key allows you to make single-shot measurements.

The **Run** key allows you to:

- put the Counter into a continuous measurement loop.
- exit any measurement after your selection of another measurement function.
- abort the current measurement by starting a new measurement (if already in Run mode or in Single mode with a measurement in progress). This also clears any statistics being processed.

The **Stop/Single** key allows you to:

- put the Counter into Single mode (if the Counter was in Run mode) where one measurement is taken with each **Stop/Single** keypress. (Stats menu item **ON SINGLE** should be set to **1**.)
- put the Counter into Single mode (if the Counter was in Run mode) where N measurements are taken with each **Stop/Single** keypress. (Stats menu item **ON SINGLE** should be set to N.)
- stop (abort) the current measurement (if the Counter was in Single mode).

Chapter 2 Operating Your Frequency Counter  
**Using the Measurement Control Keys (Run and Stop/Single)**

**To Use the Measurement Control Keys**

The following procedure demonstrates how these keys function.

**1 Connect power source to Counter, and turn on Counter.**

All segments of the front-panel display will light up while the Counter performs its power-on self-test, and then dashes are displayed. The Counter is now ready to measure frequency of a signal applied to CHANNEL 1 input. Note that the **Freq** and **Ch1** annunciators light.

**2 Connect an input signal to CHANNEL 1.**

The Counter automatically displays the measured frequency of the input signal. Note that the **Run** key indicator is ON.

**3 Press *Stop/Single* key.**

The Counter is put into Single mode and the current measurement is completed. One measurement is taken with each press of **Stop/Single** key. Note that the **Stop/Single** key indicator is ON.

**4 Press *Run* key.**

The Counter aborts any measurement in progress, and starts making repetitive measurements. That is, the Counter is in a continuous measurement loop.


**5 Press *Stop/Single* key.**

The Counter is put into Single mode.

**6 Press *Stats* key until **ON SINGLE** menu item appears, then press any one of the arrow keys to set **ON SINGLE** menu item to **N**.**

The Counter is set to take N measurements on each **Stop/Single** keypress (note: N = 100 at power-up). The state of **ON SINGLE** menu item affects the **Stop/Single** key operation while statistics are enabled.

Observe that the Stats indicator is ON. This indicates statistical processing is enabled.



Chapter 2 Operating Your Frequency Counter  
**Using the Measurement Control Keys (Run and Stop/Single)**

**7 Press *Stop/Single* key.**

One set of N frequency measurements is taken with each press of the Stop/**Single** key. One set of statistics is computed with each press of the Stop/**Single** key.

**8 Press *Stats* key until **SHOW** menu item appears.**

**9 Press any one of the arrow keys to select a statistical result to display, and press *Freq Ch 1* key.**

The Counter is now displaying one of the statistical results.

**10 Press *Stop/Single* key.**

One set of N frequency measurements is taken with each press of the Stop/**Single** key. At the completion of the Nth measurement, the Counter displays the statistical result selected in step 9.

**11 Press *Stats* key until **ON SINGLE** menu item appears, then press any one of the arrow keys to set **ON SINGLE** menu item to 1.**


The Counter is set to take one measurement on each Stop/**Single** keypress.

Disabling the statistics (with the **STATS: OFF** menu item) is another way to cause the Stop/**Single** key to initiate one measurement at a time.

---

## Using Entry/Select (Arrow) Keys

There are six entry/select keys of which four are “arrow” keys. The function of the four arrow keys and the Enter key depends on the Counter’s operating mode (that is, numeric entry, state changing, sequencing through choices in a menu, etc.). This section describes how the keys perform in the different operating modes.



### To Use During Numeric Entry

- Use the **s** key to move left to select adjustable digits (it does not wrap around).
- Use the **g** key to move right to select adjustable digits (it does not wrap around).
- Use the **d** key to increment the selected (highlighted) digit of the displayed value.
- Use the **f** key to decrement the selected (highlighted) digit of the displayed value.
- Use the **+/-** key to change the sign of the numeric value.
- Use the **Enter** key to complete a numeric entry. (If a numeric entry is changed and the **Enter** key is NOT pressed, then the value is not changed.)

### To Use When Sequencing Through the Other Meas and Recall Menus

- Use the **d** or **s** key to go back to the previous choice in a function or recall menu. Repeatedly pressing this key will cycle through (and loop around) the list of choices.
- Use the **f** or **g** key to go forward or to the next choice in a function or recall menu. Repeatedly pressing this key will cycle through (and loop around) the list of choices.
- Use the **Enter** key to select the function or execute the recall, or wait for the menu to time out for automatic selection/execution.

### To Use During State Changing (ON/OFF, LO/MED/HI, etc.)

- Press **any** of the arrow keys to toggle or change to the next state of the parameters found in the following menus:
  - Gate & ExtArm

## Chapter 2 Operating Your Frequency Counter Using Entry/Select (Arrow) Keys


- Limit Modes
  - Scale & Offset
  - Stats
  - Trigger/Sensitivity
  - 50Ω/1MΩ
  - DC/AC
  - X10 Attenuate
  - 100kHz Filter
  - Save & Print
  - Utility Menu
- The +/-key is ignored during the state changing operating mode.

### To Use on Prompted Help Messages (**MATH HELP: NO/YES, PRT HELP: NO/YES**)

- When **MATH HELP: YES** is displayed, press **Enter** key to display the “**(MEAS x SCALE) + OFFS = RESULT**” message.
- When **PRT HELP: YES** is displayed, press **Enter** key to display the “**CONFIGURE PORT ON UTILITY MENU; REMEMBER TO SAVE SETUP FIRST**” instruction.

## Using the MEASURE Menu Keys

### Overview of the MEASURE Menus



The measurement function menus are divided into three categories:

- Frequency measurements on Channel 1.
- Frequency measurements on Channel 2 (optional).
- Other measurements (period, ratio (optional), and peak voltage).

**Table 2-1. Menus of the MEASUREMENT Keys**

Freq Ch 1 key	Freq Ch 2 key	Other Meas key
FREQUENCY 1	FREQUENCY 2 (optional)	PERIOD 1 RATIO 1 TO 2 (optional) RATIO 2 TO 1 (optional) VOLT PEAKS 1

To sequence through the **Other Meas** menu, you simply need to repeatedly press the **Other Meas** key to cycle through (and loop around) the items (or measurement functions) under the key. Each press of a **Other Meas** key will advance the Counter to the next measurement function in the menu.

**NOTE**

The menus under the MEASURE keys will terminate (select function and return to measurement result display) after a short timeout.

**WARNING**

When measuring power line frequencies, be extremely careful and always use a step-down isolation transformer of which output voltage is compatible with the input measurement capabilities of this product. Since the shell of the BNC input connector is grounded to the chassis of the instrument, the hot side of an ac power line could be connected to the BNC shell and create a direct short to ground. Therefore, **NEVER TRY TO MEASURE AC POWER LINE FREQUENCIES WITHOUT AN ISOLATION TRANSFORMER.**



### To Measure Frequency

**1 Connect power source to Counter, and turn on Counter.**

All segments of the front-panel display will light up while the Counter performs its power-on self-test, and then dashes are displayed. The Counter is now ready to measure frequency of a signal applied to CHANNEL 1 input. Note that the **Freq** and **Ch1** annunciators light.

**2 Connect an input signal to CHANNEL 1.**

The Counter should automatically display the measured frequency of the input signal. The trigger levels are set to the 50% points of the signal. However, you may disable auto triggering, and change the trigger levels and slopes.

To set up CHANNEL 1's coupling, impedance, and triggering conditions to match the input signal you are trying to measure, refer to the procedures "To Select Input Coupling and Impedance" and "To Set Input Channel Trigger Level/Sensitivity" in Chapter 1, "Getting Started," or the section titled "Using CHANNEL 1 Input Conditioning Keys" in this chapter.

**3 To measure the frequency of a signal applied to the optional CHANNEL 2 input, press *Freq Ch2* key.**

**FREQUENCY 2** will be momentarily displayed and the **Freq** and **Ch2** annunciators will light. The Counter will be ready to measure the frequency of a signal applied to CHANNEL 2 input.

Note that the Frequency 2 menu item is not available in Counters that do not contain the optional Channel 2.



Chapter 2 Operating Your Frequency Counter  
Using the MEASURE Menu Keys

**To Measure Frequency Ratio (Optional)**

- 1 **Connect signals to be measured to channels 1 and 2.**
- 2 **Press *Other Meas* key until *RATIO 1 TO 2* is displayed to measure the frequency ratio between a signal applied to CHANNEL 1 input and a signal applied to the optional CHANNEL 2 input.**

***RATIO 1 TO 2*** will be momentarily displayed and the **Freq**, **Ch1**, and **Ch2** annunciators will light. The Counter will be ready to measure the frequency ratio of a signal applied to CHANNEL 1 in relation to a signal applied to CHANNEL 2 (Ch1/Ch2).

RATIO 2 TO 1 is also available (Ch2/Ch1).

Note that Ratio 1 to 2 and Ratio 2 to 1 menu items are not available in Counters that do not contain the optional Channel 2.


Note the result is not scaled by 100; it is not a percentage.

The front-panel “arrow” (or entry/select) keys can also be used when sequencing through the **Other Meas** menu. Refer to the section titled “Using Entry/Select (Arrow) Keys” for details.

**To Measure Period**

**Press *Other Meas* key until *PERIOD 1* is displayed.**

***PERIOD 1*** is momentarily displayed, the **Period** and **Ch1** annunciators light, and the Counter is ready to measure the period of a signal applied to CHANNEL 1.



Chapter 2 Operating Your Frequency Counter  
Using the MEASURE Menu Keys

**To Measure Positive/Negative Volt Peaks**

Press *Other Meas* key until **VOLT PEAKS 1** is displayed.

**VOLT PEAKS 1** is momentarily displayed, the **Ch1** annunciator lights, and the Counter is ready to measure minimum and maximum voltage peaks of signals applied to CHANNEL 1.

2

---

**NOTE**

In Volt Peaks function, the Counter measures the input signal *after* the signal has been conditioned by the input settings (impedance, coupling, attenuation, and filter). One reminder of this is the (**AC COUPLED**) message, which is displayed when Voltage Peaks is selected and the measurement channel is ac coupled.

The result is corrected for X10 attenuation.

---

**NOTE**

Arming is not used for Voltage Peaks measurements. Also, Limits, Math, and Display Digits are not available for Voltage Peaks measurements.

---

---

## Using the Gate & External Arm Menu Key

### Overview of Gate/External Arming Functions




Table 2-2 lists the menus for all the arming configurations, and shows how the Gate and External Arming menu changes as a function of the arming mode.

The Counter has four arming modes: auto, external, digits and time. The arming modes are defined in the following paragraphs.

#### *TIME Arming*

For frequency, period, and frequency ratio, **time arming** means you can set the gate time—the length of time for which your signal is measured.

---

#### **NOTE**

Gate time and resolution are linked: the longer the gate time, the greater the resolution. With an increase in resolution, you get a larger number of digits on the display.

Time arming is demonstrated in the sub-section titled “Example Procedure for Gate and External Arm.”

#### *AUTO Arming*

For frequency, period, and frequency ratio, **auto arming** means make individual measurements as fast as possible.

#### *EXTERNAL Arming*

For frequency, period, and frequency ratio, **external arming** means you can start a measurement by using an external signal.

---

#### **NOTE**

When external arming mode is enabled, a signal must be connected to the Counter’s rear-panel **Ext Arm** connector.

Chapter 2 Operating Your Frequency Counter  
**Using the Gate & External Arm Menu Key**

***DIGITS Arming***

For frequency, period, and frequency ratio, **digits arming** means you can set the number of digits of resolution that you require your result to provide.


Digits arming is demonstrated in the sub-section titled “Example Procedure for Changing the Number of Digits Displayed.”

**\*Table 2-2. The Gate & External Arm Key Menus as a Function of the Arming Mode**

<b>Frequency, Period, Ratio</b>
<b>Time Arming:</b> GATE: TIME TIME: <time>
<b>Auto Arming:</b> GATE: AUTO
<b>Digits Arming:</b> GATE: DIGITS DIGITS: <digits>
<b>External Arming</b> (Refer to page 2-17 or the Menu Roadmap in the Quick Reference Guide, which follows the Preface, for more information.): GATE: EXTERNAL START: POS NEG STOP: AUTO NEG POS TIME TIME: <time>

---

\* There is no Gate and External Arm menu available for Voltage Peaks measurements.





## To Use the Gate and External Arm

### Example Procedure for Gate and External Arm

For demonstration purposes, you want to set up the Counter so that it uses an external arm to start a measurement. You want to make a Frequency measurement on a signal applied to channel 1. Also, you want to perform the measurement during an interval of 5 milliseconds as shown in the following figure.

**NOTE**

As shown in the following figure, the Counter is always synchronized to the input signal. Arming occurs on the rising edge of external arm (ExtArm), and the measurement gate is synchronized to the trigger event on CHANNEL 1.



Perform the following procedure to accomplish this task.

- 1 Turn on the Counter, and press *Stop/Single* to put the Counter into the single measurement mode.
- 2 Connect the signal to channel 1 input, and press *Freq Ch 1* key.
- 3 Connect an external TTL signal to the Counter's rear-panel *Ext Arm* connector.
- 4 Press *Gate & ExtArm* key.  
**GATE: TIME** is displayed.
- 5 Press any one of the arrow keys until **GATE: EXTERNL** is displayed.
- 6 Press *Gate & ExtArm* or *Enter* key.

Chapter 2 Operating Your Frequency Counter  
Using the Gate & External Arm Menu Key

**START: POS** is displayed. (If **START: NEG** is displayed instead, then press any one of the arrow keys to toggle to the next state—**POS**).

7 Press *Gate & ExtArm* or *Enter* key.

**STOP: NEG** is displayed.

8 Press any one of the arrow keys until **STOP: TIME** is displayed.

9 Set the Gate Time to 5 ms by performing the following steps:

a. Press **Gate & ExtArm** or **Enter** key.

**TIME:** .100 seconds (the default time) is displayed.

b. Press the appropriate arrow keys until **TIME:** .00500 s is displayed.

c. Press **Enter** key.

---

**NOTE**

---

**BE SURE to press the *Enter* key to complete the numeric entry.**

The counter will now gate for a duration of 5 ms. The 5 ms interval will begin after the external edge is detected.

10 Press *Stop/Single* key to start the measurement.

The measurement is started after the external arm pulse occurs.

Chapter 2 Operating Your Frequency Counter  
Using the Gate & External Arm Menu Key

*Example Procedure for Changing the Number of Digits of Resolution Displayed for More Precise Measurements*

- 1 Turn **POWER** key OFF then ON again (cycle **POWER** key) to preset the Counter.
- 2 Connect (for demonstration purposes) the **10 MHz Out** signal to the channel 1 input.
- 3 Press **Other Meas** key until **PERIOD 1** is displayed.

After a few seconds, **0.100,000,000,0**  $\mu\text{s}$  is displayed. Hence, the default number of digits (or resolution) displays a precise measurement.

- 4 To demonstrate how to use “digits arming” to change the number of digits displayed, perform the following steps first.
  - a. Press **Gate & ExtArm** key  
**GATE: TIME** is displayed.
  - b. Press any one of the arrow keys until **AUTO** is displayed.
  - c. Press **Enter** or **Run** key.  
**0.100,0**  $\mu\text{s}$  is displayed. Note that fewer digits are displayed.

In “auto arming” you produce results quickly. The short gate time produces a lower-resolution result.

Chapter 2 Operating Your Frequency Counter  
Using the Gate & External Arm Menu Key

- 5 To change the display to the better measurement resolution using digits arming, perform the following steps:
- a. Press **Gate & ExtArm** key  
**GATE: AUTO** is displayed.
  - b. Press any one of the arrow keys until **DIGITS** is displayed.
  - c. Press **Gate & ExtArm** or **Enter** key.  
**DIGITS: 4** is displayed (the default number of digits)
  - d. To set the number of digits displayed to 8, press the appropriate arrow keys until **DIGITS: 8** is displayed.
  - e. Press **Enter** key.
  - f. Press **Run** key.  
**0.100,000,000**  $\mu\text{s}$  is displayed.

Note that 8 digits of resolution are displayed ( $0.100,000,000^{\text{1 2 3 4 5 6 7 8}} \mu\text{s}$ ).


For the convenience of the user, the leading “1” does not count as a digit when 8 digits are selected; thus, a result of **0.099,999,999**  $\mu\text{s}$  can alternate with a result of **0.100,000,000**  $\mu\text{s}$  with a stable display, and no change of settings is required.



---

## Using the MATH Menu Keys

Note that Math and Limits are not available for Voltage Peaks measurements.



### Overview of Scale/Offset Math Menu

The Scale and Offset functions within the Math menu allow you to perform simple mathematical operations on the measurement result before it is displayed. The Scale and Offset functions allow for multiplication and addition. Modification of the displayed measurement by these math operations is represented by the following equation:

$$(\text{Measurement} \times \text{Scale}) + \text{Offset} = \text{Displayed Result}$$

The math operations can be used, for example, to subtract systematic errors or display the percentage difference between signals. Also, the overall math operation can be disabled and then re-established without having to re-enter constants.

The menu items of the Scale and Offset Math functions allow you to:

- enter a desired multiplication factor for a measurement (**SCAL:**).
- enter a desired addition or subtraction value for a measurement (**OFFS:**).
- get and display the last measurement value, and use it as a negative offset (**SET REF: NO** or **YES**).
- disable or enable the Math mode (**MATH: OFF** or **ON**)—Note that the Math mode is automatically enabled when you enter the scale and/or offset value(s); thus, the primary function of this menu item is to allow you to turn the Math mode off.
- get Help, which displays the equation “**(MEAS X SCALE) + OFFS = RESULT**” to tell you how the scale and offset results are computed by the Counter (**MATH HELP: NO** or **YES**).

### To Use the Scale/Offset Math Menu

#### Example Procedure for Scale Function

For demonstration purposes, you have a motor that has a tachometer attached to its rotating shaft that generates a pulse for every revolution of the shaft.

Your task is to measure the speed or revolutions per minute (rpm) of the tachometer's output, and make the Counter directly display the measurement in rpm (which is fundamentally a frequency measurement). The equation for this task is:

$$\text{Frequency (Revolution/Sec)} \times \text{Scale (60 Sec/Min)} = \text{Results (Revolution/Min)}$$

Perform the following procedure to accomplish this task.

- 1 **Connect the output to channel 1 input, and press *Freq Ch 1* key.**

The frequency of the signal is displayed.

- 2 **Press *Scale & Offset* key until **SCAL: 1.000000** is displayed.**
- 3 **Set the Scale to 60 (since there are sixty seconds in a minute) by performing the following steps:**
  - a. Press appropriate arrow keys to set Scale to 60.
  - b. Press **Enter** key.

---

**NOTE**

---

**BE SURE to press the *Enter* key to complete the numeric entry.**

The scale is now set to 60.

When the scale factor is set, both scale and offset are applied to the measurement result. Verify that the offset value is zero for applications requiring only scale by performing the following step.

- 4 **Press *Scale & Offset* key, if required, until **OFFS:** is displayed.**

**OFFS: 0.000000** should be displayed. If the Offset value is not set to "0.000000":

Chapter 2 Operating Your Frequency Counter  
Using the MATH Menu Keys

- a. Press the appropriate arrow keys to set the Offset to “0.000000.”
- b. Press **Enter** key.

---

**NOTE**

---

**BE SURE to press the *Enter* key to complete the numeric entry.**

The offset is now set to 0.

**5 Press *Run* key.**

The rpm measurement is displayed.

Note that units indicators **Hz** and **s** do not appear when MATH is ON.

***Example Procedure for Offset Function***

The offset function can be used to add or subtract a fixed value from measurement results. This can be very useful, for example, when tuning or aligning odd frequencies of a local oscillator (LO). The target frequency can be entered as a negative offset, then the Counter can display the differences between the LO's frequency and the target frequency. You can then adjust the LO until zero is displayed in the Counter's display.

Your task is to use the offset function to tune or align an LO to the target frequency of 222.127 MHz. Perform the following procedure to accomplish this task.

- 1 Cycle *POWER* key to preset the Counter.**
- 2 Connect the LO to channel 1, and press *Freq Ch 1* key to measure the frequency of the LO.**
- 3 Press *Scale & Offset* key until **SCAL:** is displayed.**
- 4 Set Scale to “1” by pressing the appropriate arrow keys to enter the value 1.000000 if Scale is not already set to “1.”**
- 5 Press *Enter* key.**

---

**NOTE**

---

**BE SURE to press the *Enter* key to complete the numeric entry.**

Chapter 2 Operating Your Frequency Counter  
Using the MATH Menu Keys

- 6 Press *Scale & Offset* key, if required, until **OFFS:** is displayed.

**OFFS:** 0.000000 should be displayed. This is the default value.

- 7 Set the Offset to -222.127 MHz.

Refer to the sub-section titled “Entering the Offset Value” in Chapter 1, “Getting Started,” for details on how to perform numeric entry for Offset.

- a. Use the appropriate combination of the arrow keys to display a value of 222.127 MHz.
- b. Press +/-key, which is located below the arrow keys, to change the plus sign to minus.

**OFFS:** -222.127 MHz is displayed.

- c. Press **Enter** key.

---

**NOTE**

---

**BE SURE** to press the *Enter* key to complete numeric entry.

- 8 Press *Run* key.

The resultant frequency is displayed with -222.127 MHz subtracted from each measurement result.

The Counter displays the error or differences from the targeted 222.127 MHz.

For example, the display might indicate **+000.023 MHz**.

- 9 Adjust the LO as necessary until the Counter displays zero (00.000,000,0).

Your local oscillator is now properly aligned.

**Example Procedure for Turning Off Math Mode**

- 1 Press *Scale & Offset* key until **MATH: ON** is displayed.
- 2 Press any one of the arrow keys.

## Chapter 2 Operating Your Frequency Counter

### Using the MATH Menu Keys

**MATH: OFF** is displayed. Now, Scale and Offset no longer are used to modify the displayed result.

- 3 Press **Run** key to return the Counter to its normal operation.

#### *Example Procedure for Set Reference Function—Offset From the Last Measurement Value (Seeing Digits Not Visible on the 12-Digit Display)*

The **SET REF: YES** menu item uses the negative of the last measurement value, rounded to eleven digits, to set the OFFSET. It also resets the scale value to 1.0. Thus, any difference in the offset (or now the reference value) and the current measurement value is displayed.

Let's assume you are measuring the frequency of a stable source, but you are only interested in the least significant digits of the measurement. Use the **SET REF: YES** menu item to configure the appropriate OFFSET value.

Your task is to measure a stable source to obtain the changes in the least significant digits.

- 1 Cycle **POWER** key to preset the Counter.
- 2 Change gate time to 15.0 seconds on **GATE** menu.
- 3 To demonstrate **SET REF:**, connect a 10 MHz sine wave signal to channel 1 of the Counter, and press **Freq Ch 1** key.

(Note that since the gate time is set to 15 seconds, it will take about 15 seconds to for the Counter to display the measurement.)

**10.000,000,000,1 MHz** is displayed.

- 4 Press **Scale & Offset** key until **SET REF:** is displayed.
- 5 Press the any one of the arrow keys to select **SET REF: YES**, and press **Enter** key.

**OFFS: -10.00000 M** is displayed, for example.

### Using the MATH Menu Keys

Note that this value represents the last measurement of the input signal rounded to eleven digits. The Counter uses it as the reference offset value, and reverses the sign from + to –.

**6 Press *Run* key.**

$-12^* \mu$  (120  $\mu$ s) is displayed, for example, at the completion of the next measurement.

This value (-0.00012) is the small difference between the signal being measured and the reference value (**OFFS: -10.00000 M**) obtained in step 5.

Using the reference allows you to observe small differences in the 13th–15th digits which would not be observable in the 12-digit display.

### Overview of Statistics (Stats) Menu

The Stats menu allows you to:

- select which computed statistics you want displayed (**SHOW: STD DEV, MEAN, MAX, or MIN**).
- choose between having the actual measurement or statistical result displayed (**SHOW: MEAS**).
- select the number of measurements you want to make for each computed statistic (**N:**).
- enable or disable the Stats mode (**STATS: ON or OFF**).
- enable the Counter to perform statistical computation on only measurements that are within the user-entered limits; that is, filter data (**USE: IN LIMIT**), or
- enable the Counter to perform statistical computation on all measurements, whether they fall in or out of the user-entered limits (**USE: ALL MEAS**).
- configure Stop/**Single** key to initiate a set of N measurements (**ON SINGLE: 1 or N**).

## To Use the Stats Menu for Automatic and Continuous Statistical Analysis

### *Example Procedure for Computing Stats*

For demonstration purposes, let's say you need to know the mean (average) and minimum frequency values of a signal. Also, you want the Counter to make 20 measurements before it performs these statistical computations.

Perform the following procedure to accomplish this task.

- 1 **Connect the signal to channel 1 input, and press *Freq Ch 1* key.**
- 2 **Press *Stats* key until *N:* is displayed.**  
*N:*     100 is displayed (100 is the default value).
- 3 **Set *N* to 20 (since you want the Counter to make 20 measurements before computing the mean and minimum values) by pressing the appropriate arrow keys.**  
*N:*     20 is displayed.
- 4 **Press *Enter* key.**

---

**NOTE**

---

**BE SURE to press the *Enter* key to complete numeric entry.**

The Counter is now set to make 20 measurements before computing statistics.

- 5 **Press *Stats* key until *SHOW:* is displayed.**
- 6 **Press any one of the arrow keys until *SHOW: MEAN* is displayed.**

## Chapter 2 Operating Your Frequency Counter

### Using the MATH Menu Keys

#### 7 Press *Run* key.

Immediately after the **Run** key is pressed, the Counter momentarily displays **DOING STATS**. When the Counter has made 20 valid measurements, it then displays the **mean** frequency value of the input signal.

---

**NOTE**

---

The Counter will display updated statistics results every 20 measurements.

#### 8 Press *Stop/Single* key after you have a mean value displayed.

#### 9 To display the *minimum* frequency value, perform the following:

- a. Press **Stats** key.
- b. Press any one of the arrow keys until **SHOW: MIN** is displayed.
- c. Press **Freq Ch 1** key.

---

**CAUTION**

---

Pressing the **Run** key now would clear the present statistics results and calculate a new set of results after “N” measurements.

#### *Example Procedure for Easy Viewing of Stats*

The d and f arrow keys provide a short cut to viewing each of the stats (that is, standard deviation, mean, maximum, and minimum) when the Counter is already displaying a statistic measurement. These keys allow you to cycle through the different Stats results and automatically view them.

**While the Counter is displaying a statistics measurement, press either the d or f arrow key to cycle through and display each of the four computed statistics, and the current measurement.**

---

**NOTE**

---

The **Display Digits** keys (that is, **More Digits** and **Fewer Digits**) do NOT affect standard deviation display results.



Chapter 2 Operating Your Frequency Counter  
Using the MATH Menu Keys

*Example Procedure for Filtering Data (Using Limits) During Stats*

- 1 Using the procedure in the previous sub-section titled “Example Procedure for Computing Stats,” set up the Counter to display the minimum frequency value of an input signal.
- 2 Set the upper and lower limits. (Refer to the section in Chapter 1 titled “To Set Limits of Measurements” if needed.)
- 3 Press *Stats* key until **USE:** is displayed.
- 4 Press one of the arrow keys to toggle to **IN LIMIT** state.

**USE: IN LIMIT** is displayed.

- 5 Press *Run* key.

The Counter will now perform the statistical computations (that is, standard deviation, mean, maximum, and minimum) on only those measurements that are within the user-entered limits. The Counter then displays the statistics you picked (minimum, in this case).

- 6 Press *Stats* key until **USE:** is displayed.
- 7 Press any one of the arrow keys to toggle to **ALL MEAS** state.

**USE: ALL MEAS** is displayed.

- 8 Press *Run* key.

The Counter will now perform the statistical computations (that is, standard deviation, mean, maximum, and minimum) on all measurements, whether they fall in or out of the user-entered limits. The Counter then displays the statistic you picked (minimum, in this case).

Chapter 2 Operating Your Frequency Counter  
**Using the MATH Menu Keys**

*Example Procedure for Configuring SINGLE to Initiate N Measurements*

Please refer to the procedure titled “To Use the Measurement Control Keys” on page 2-7 in this chapter for an example use of ON SINGLE.


*Example Procedure for Turning Off Stats Mode*

- 1 Press *Stats* key until **STATS: ON** is displayed.
- 2 Press any one of the arrow keys.  
**STATS : OFF** is displayed.
- 3 Press *Run* key to return the Counter to its normal operation.

---

## Using the LIMITS Menu Keys

Note that Math and Limits menus are not available for Voltage Peaks measurements.



### Overview of Limits Menus

The menu items under the Limits keys allow you to:

- select the desired upper and lower measurement limits (**UPPR:**, **LOWR:**).
- disable or enable Limit Testing (**LIM TEST: OFF** or **ON**)—Note that the Limit Testing is automatically enabled when you set the upper and lower limits, or update any menu item in the Limit Modes menu; thus, the primary function of the LIM TEST menu item is to allow you to turn Limit Testing off.
- set the Counter to stop making measurements when a measurement exceeds the user-entered limits (**ON FAIL: STOP**). (Stop on limits does not have any effect if the Counter is in the single measurement mode.)
- enable the Counter to continue taking measurements after a measurement exceeds the user-entered limits (**ON FAIL: GO ON**).
- change the Counter display from numeric to analog graph to quickly visualize changes in the signal (or to quickly see when measurements are in or out of limits) (**SHOW: NUMBER** or **GRAPH**).

## To Set and Use Automatic Limit Testing

### *Limits Testing Example 1—Flag and Stop Measuring On Limits*

Automatic limit testing can be used to monitor a test signal to assure that it does not drift outside of a user-entered set of limits.

For demonstration purposes, you want to first measure the frequency of a 10 MHz signal applied to channel 1 of the Counter. Next, you want to set limits that would cause the Counter to flag (turn on the Limits annunciator in the front-panel display) and stop making measurements if this signal drifts more than  $\pm 1$  kHz.

- 1 **Connect the 10 MHz input signal to channel 1 of the Counter, and press *Freq Ch 1* key.**

**Assume that the frequency measured is 10 MHz.** If the drift is not to be larger than  $\pm 1$  kHz, then the upper limit should be set to **10.001 MHz** and the lower limit to **9.999 MHz**. Let's set these values in the following steps.

- 2 **Press *Uppr/Lower* key until **UPPR:** is displayed.**

**UPPR: 0.000000** is displayed (0 is the default value).

- 3 **Set **UPPR** to 10.001 MHz.** (Refer to the section in Chapter 1 titled "To Set Limits of Measurements" if needed.)

---

**NOTE**

---

After you enter the value 10.001 MHz, **BE SURE** to press the *Enter* key to complete the entry.

- 4 **Press *Uppr/Lower* key, if required, until **LOWR:** is displayed.**

**LOWR: 0.000000** is displayed (0 is the default value).

Chapter 2 Operating Your Frequency Counter  
Using the LIMITS Menu Keys

- 5 Set **LOWR** to 9.999 MHz.

---

**NOTE**

---

After you enter the value 9.999 MHz, BE SURE to press the *Enter* key to complete the entry.

- 6 Press *Limit Modes* key until **LIM TEST: ON** is displayed.

Note that once either the upper or lower limits have been set, the limit testing is automatically enabled as indicated by the **LIM TEST: ON** display, and the Limit Modes indicator.

- 7 Press *Limit Modes* key.

**ON FAIL: GO ON** is displayed.

- 8 Press any one of the arrow keys to toggle to the next state.

**ON FAIL: STOP** is displayed. The **ON FAIL: STOP** function tells the Counter to stop making measurements when the input signal drifts more than  $\pm 1$  kHz.

- 9 Press *Run* key to start making measurements with this limits-testing choice selected.

Now, if a measurement drifts out of the user-entered limits the **Limit** annunciator in the display will light. The Counter will stop making measurements and hold the out-of-limit measurement in the display.

Chapter 2 Operating Your Frequency Counter  
Using the LIMITS Menu Keys

*Limits Testing Example 2—Flag On Limits but Continue Measuring*

If you decide that you want the Counter to flag measurements that are out of limits but to continue taking measurements, then perform the following steps.

- 1 Press *Limit Modes* key until **ON FAIL: STOP** is displayed.
- 2 Press any one of the arrow keys to toggle to the next state.

**ON FAIL: GO ON** is displayed.

- 3 Press *Run* key to start making measurements with this limits-testing choice selected.

Now, each time a measurement drifts out of the user-entered limits the **Limit** annunciator in the display will light, but the Counter will continue to make measurements.

The Limit annunciator will go on whenever a result is out of limits. As soon as a result is within limits, the Limit annunciator will go off.


*Limits Testing Example 3—Use Analog Graph Display While Adjusting/Aligning Input Signal*

- 1 For demonstration purposes, connect a 10 MHz signal to channel 1, and press *Freq Ch 1* key.
- 2 Using the *Uppr & Lower* key, set the upper limit to 10.2 MHz and the lower limit to 9.8 MHz. (Refer to the section in Chapter 1 titled “To Set Limits of Measurements” if needed.)
- 3 Press *Limit Modes* key until **SHOW: NUMBER** is displayed.
- 4 Press any one of the arrow keys to toggle to the next state.

**SHOW: GRAPH** is displayed.


Chapter 2 Operating Your Frequency Counter  
Using the LIMITS Menu Keys

- 5 Press *Run* key to display the graph as shown below.




The asterisk represents the measurement and the colons (:) represent the limits you set. This graph indicates that the measurement is within the limits. The colon to the left represents the lower limit, and the colon to the right represents the upper limit.

- 6 Adjust your signal down to 9.7 MHz.




The asterisk is now out of the limits as it is below the entered 9.8 MHz lower limit. (Note the **Limit** annunciator lights since the signal is out of limits.)

- 7 Now, adjust your signal up to 10.3 MHz.



The asterisk is now out of the limits as it has exceeded the entered 10.2 MHz upper limit. (Note the **Limit** annunciator lights since the signal is out of limits.)



Chapter 2 Operating Your Frequency Counter  
Using the LIMITS Menu Keys

- 8 To change the Counter back to displaying numbers, press *Limit Modes* key until **SHOW: GRAPH** is displayed.
- 9 Press any one of the arrow keys to toggle to **SHOW: NUMBER**.
- 10 Press *Run* key to display measurements as numbers.

*Limits Testing Example 4—Selecting Filtering Conditions of Stats Computation*

Let's assume you have set the upper and lower limits to reasonable values as in the previous procedure.

**NOTE**

Since the Limit Testing and Stats functions are independent, **LIM TEST:** doesn't have to be ON in order to filter measurements for statistics.

- 1 Press *Stats* key until **USE: ALL MEAS** is displayed.
- 2 Press any one of the arrow keys to display **USE: IN LIMIT**.
- 3 Press *Run* key to start the measurement.

The Counter will compute statistics using only measurements that are within the user-entered limits.

- 4 Press *Stats* key until **USE: IN LIMIT** is displayed.
- 5 Press any one of the arrow keys to display **USE: ALL MEAS**.

The Counter will compute statistics using all measurements, whether they fall in or out of the user-entered limits.



Chapter 2 Operating Your Frequency Counter  
Using the LIMITS Menu Keys

- 6 Press *Run* key to start the measurement.
- 7 To turn off the Limit Testing, perform the following steps:
  - a. Press **Limit Modes** key until **LIM TEST: ON** is displayed.
  - b. Press any one of the arrow keys to toggle Limits OFF.  
**LIM TEST: OFF** is displayed.

When Limit Testing is off, the **Limit** annunciator, the stop-on-limit capability, the limit graph, and the rear panel RS-232 Limit Output (if DTR: LIMIT choice was selected as described in the following Example 5 procedure) are disabled.

---

**NOTE**

---

Stats will still filter data using your upper and lower limits if you set Stats to USE: IN LIMIT.

- 8 Press *Run* key to return the Counter to computing statistics on all measurements.

*Limits Testing Example 5—Sending the Limit-Detect Output to the RS-232 Serial Port*

---

**NOTE**

---

If you cycle power, you will lose everything except saved measurement setups and special parameters saved to non-volatile memory; therefore, make sure you use the Save and Recall functions of the Counter to retain the measurement setup prior to powering down to set up the Limit-Detect Output line (pin 4) of the RS-232 serial connector. Refer to the appropriate section in this chapter for details on how to use Save and Recall.


- 1 **To use the Limit-detect output from the serial port, perform the following steps:**
  - a. Save your measurement setup that includes your Limit Testing choices, by simply pressing the **Save & Print** key until **SAVE: 1** is displayed, then **Enter** key to save to register 1.
  - b. Turn off the Counter.
  - c. Press and hold **Recall (Utility)** key, then press **POWER** key.
  - d. Press **Recall (Utility)** key until **DTR:** is displayed.
  - e. Press any one of the arrow keys until **DTR: LIMIT** is displayed.
- 2 **Press *Run* key.**
- 3 **Press *Recall (Utility)* key until **RECALL 1** is displayed, then wait a few seconds to recall the measurement setup saved in register 1.**

Since your measurement setup included your settings for upper and lower limits, and **LIM TEST:** was set to **ON**, the Counter is now set for limit testing with the Limit-detect output.

If a measurement drifts out of the user-entered limits, the Limit annunciator in the display will light. Also, pin 4 on the RS 232 connector will change state (to a low-voltage RS-232 level) to flag each time a measurement drifts out of the limits. (RS-232 voltage levels swing from  $\pm 12V$ .)

---

## Using the DISPLAY Digits Keys



### Overview of the DISPLAY Digits Keys

The **DISPLAY Digits** keys allow you to control the displayed digits only; these keys do not change measurements. Each press of the **Fewer Digits** key blanks out a digit with an underscore ( \_ ), whereas each press of the **More Digits** key re-displays the digit. A minimum of three digits is displayed, no matter how many times you press the **Fewer Digits** key.

The **More Digits** key allows you to display the maximum number of digits for the current arming setting. To get more digits displayed for a measurement, refer to the sub-section titled “TIME Arming” (page 2-15) in this chapter for information on using the **Gate & ExtArm** key to change the gate time/resolution. Also, refer to the “Example Procedure for Changing the Number of Digits of Resolution Displayed for More Precise Measurements” (page 2-19 in this chapter) for instructions on how to change arming by selecting a number of digits.

Printed output is the same as the display.

---

**NOTE**

---

The **Display Digits** keys operate for all measurements and statistics (means, maximum, etc.) except for Voltage Peaks and standard deviation.

---

**NOTE**

---

Each time the Counter’s measurement function (i.e., period, frequency etc.) or arming is changed, the Counter’s display is reset to display all digits.

Chapter 2 Operating Your Frequency Counter  
**Using the DISPLAY Digits Keys**

**To Use the DISPLAY Digits Keys**

The following step-by-step procedure describes how to use the **Display Digits** keys. In this procedure, you are instructed to blank out all digits below 1 kHz for easier reading.

- 1 Cycle *POWER* key to preset the Counter.
- 2 For demonstration purposes, connect the Counter's rear-panel *10 MHz Out* signal to channel 1 of the Counter, and press *Freq Ch 1* key to measure the frequency of this signal.


*10.000,000,0 MHz* is displayed.

- 3 To blank all digits below 1 kHz, press *DISPLAY s (Fewer Digits)* key four times.

*10.000, \_ \_ \_ , \_ MHz* is displayed.

---

## Using CHANNEL 1 Input Conditioning Keys



The **Trigger/Sensitivity** keys are menu keys, while the other keys in this group (that is, **50Ω/1MΩ**, **DC/AC**, **X10 Attenuate**, and **100kHz Filter**) are toggle keys.

Use the CHANNEL 1 group of keys to set up the Counter's input conditions for measuring input signals applied to CHANNEL 1. (The Trigger/Sensitivity menu is unavailable for Voltage Peaks measurements.)

### Overview of Trigger/Sensitivity Menu

---

**NOTE**

Most of the measurement functions (that is, frequency, period, and ratio) automatically set the auto trigger mode and trigger level. The Trigger/Sensitivity menu items allow you to override the automatic settings.

The menu items under the Trigger/Sensitivity key allows you to manually:

- select the auto trigger mode (**AUTO TRIG: ON** or **OFF**).

If auto trigger is OFF, you are allowed to:

- select the voltage level at which CHANNEL 1 will trigger (**LEVEL: *n* V**, where *n* is a numeric value).

If auto trigger is ON, you are allowed to:

- select the percentage of an input signal at which the Counter will trigger (**LEVEL: *n* PCT**, where *n* is a numeric value).

Setting **AUTO TRIG:** to ON causes the Counter to measure and compute a trigger level corresponding to the auto-trigger percentage of CHANNEL 1.

---

**NOTE**

The optional Channel 2 RF Input (Option 015, 030, or 050) requires no manual input conditioning. Just connect the RF signal to CHANNEL 2 and the Counter measures the signal.


## Chapter 2 Operating Your Frequency Counter Using CHANNEL 1 Input Conditioning Keys

While AUTO TRIG: is ON, the Counter will, for each measurement, check that the measurement signal is triggering at the current level. If no triggering is found, the Counter will measure and compute a new trigger level. (While AUTO TRIG: is ON, the Counter also measures and computes a new trigger level whenever measuring is invoked with the front-panel Stop/**Single** and **Run** keys, or whenever the auto-trigger percentage is updated.)

The menu items under the Trigger/Sensitivity key also allows you to manually:

- select what slope or edge (positive or negative) of an input signal will trigger the Counter (**SLOPE: POS** or **NEG**).
- select medium, high, or low sensitivity levels (thus, varying the hysteresis window or trigger band) for the optimum sensitivity for certain measurement applications (**SENSTVTY: MED, HI, or LOW**).



**DEFINITION OF SENSITIVITY.** Sensitivity is the lowest amplitude signal at a particular frequency that the Counter will count. The amplifier gain and the voltage difference between the input trigger hysteresis levels determine the Counter's sensitivity. Sensitivity is specified with the trigger level set at a value equal to the midpoint of the input signal. The input waveform must cross both the upper and lower hysteresis levels to generate a count as shown in the following figure.




**Signal crosses through both hysteresis levels to effect a count.**

Chapter 2 Operating Your Frequency Counter  
Using CHANNEL 1 Input Conditioning Keys

If the signal peaks do not exceed beyond both hysteresis limits, the input signal will not generate a count. For example, the peak-to-peak amplitude is insufficient, or trigger level is set above or below the midpoint of the input signal as shown in the following figures.



**Signal will not generate a count because the peak-to-peak amplitude of the signal is insufficient.**



**Signal will not generate a count because the trigger level is set below the midpoint of the signal, causing the lower hysteresis level to not be crossed.**

## Chapter 2 Operating Your Frequency Counter Using CHANNEL 1 Input Conditioning Keys

The sensitivity specification is given in terms of volts rms for applications that involve measuring a sine wave signal, though it should be noted that a different waveform with the same rms voltage may not trigger a count.

Since the Counter input does not respond to the rms value of the waveform but only to the peak-to-peak value, the sensitivity specification is also given for volts peak-to-peak with a minimum pulse width.

As previously mentioned, the sensitivity of the Counter can be changed by using the **SENSTVTY: MED, HI, or LOW** menu choices in the **Trigger/Sensitivity key** menu for optimum sensitivity for certain measurement applications. For example, low sensitivity setting is very useful when measuring noisy signals.

### To Use the Trigger/Sensitivity Key to Adjust Counter's Trigger Voltage and Sensitivity Levels

- 1 Turn **POWER** key OFF then ON again (cycle **POWER key**) to preset the Counter.
- 2 Connect a signal to CHANNEL 1 input, and press **Freq Ch 1** key to measure the frequency of the signal.
- 3 Press CHANNEL 1 **Trigger/Sensitivity key**.

**AUTO TRG: ON** is displayed.

Note that the Trigger/Sensitivity LED indicator is on, corresponding to AUTO TRG: ON.

- 4 Press any one of the arrow keys to toggle to the auto trigger off mode.

**AUTO TRG: OFF** is displayed.

Note that the Trigger/Sensitivity LED indicator is off, corresponding to AUTO TRG: OFF.



Chapter 2 Operating Your Frequency Counter  
Using CHANNEL 1 Input Conditioning Keys

5 Press *Trigger/Sensitivity* or *Enter* key.

**LEVEL:** 0.000V is displayed. (Actual value may be different.)


6 Suppose you want to set the trigger level to 1V. Perform the following steps:

Press the appropriate arrow keys until **LEVEL:** 1.000V is displayed.

**NOTE**


The trigger level adjustment is “live.” The CHANNEL 1 LED indicates the trigger state (that is, flashing when triggering, ON when trigger is too low, and OFF when trigger is too high).

The trigger voltage level for CHANNEL 1 is now set to 1V as shown in the following figure.




7 Press *Trigger/Sensitivity* or *Enter* key.

**SLOPE:** POS is displayed. The trigger slope is set at positive; thus, the Counter triggers on the rising edge of the input signal as shown in the following figure.




If you want to trigger on the negative (or falling) edge of the input signal, then perform the following step.



Chapter 2 Operating Your Frequency Counter  
Using CHANNEL 1 Input Conditioning Keys

- 8 Press any one of the arrow keys until **SLOPE: NEG** is displayed.


The trigger is set at negative; thus, the Counter triggers on the falling edge of the input signal as shown in the following figure.



- 9 To set the input channel sensitivity, press *Trigger/Sensitivity* key until **SENSTVTY: HI** is displayed.

If sensitivity is not set to HI, then press any one of the arrow keys to change to HI.

The Counter's CHANNEL 1 sensitivity is set high as shown in the following figure. Refer to the section titled "DEFINITION OF SENSITIVITY" on page 2-42 in this chapter for information on sensitivity.




The Counter should now be triggering as determined by the sensitivity level, and displaying the input signal's frequency if the input signal peak-to-peak voltage is large enough for the selected sensitivity level.

The signal must travel completely through the trigger band before a valid trigger is recognized.

## Chapter 2 Operating Your Frequency Counter Using CHANNEL 1 Input Conditioning Keys

- 10 Press any one of the arrow keys until **SENSTVTY: LO** is displayed.

The Counter's CHANNEL 1 sensitivity is set low as shown in the following figure.



### Overview of Input Conditioning Toggle Keys

The toggle keys of CHANNEL 1 allow you to:

- select 50 $\Omega$  input impedance or 1 M $\Omega$  input impedance for the input channel (**CH 1: 50 OHM**, or **1M OHM**).
- select dc coupling or ac coupling for the input channel (**CH 1: DC**, or **AC**).
- select the attenuation of signals at the input channel. The normal or “no” attenuation state (key indicator OFF) connects the input signal directly to the input amplifier. The X10 state attenuates the input signal by a factor of 10.
- insert a low pass filter into the input channel, which attenuates frequencies above 100 kHz. When the 100 kHz filter is enabled, the key indicator is ON. When the filter is disabled (key indicator OFF), the Counter resumes normal operation over the entire bandwidth (**CH 1: LP FILT**, or **NO FILT**).

Use the low pass filter for input signals that are very low frequency but noisy to prevent the Counter from counting unwanted noise, which will distort your measurement.

---

## Using the Save and Recall Menus



### Overview of Save and Recall Functions

The combined use of the Save and Recall functions allows you to save and recall the measurement setups which determine how the Counter measures, analyzes, and reports answers. A setup can include the measurement to be made, the precision desired, offset and scaling factor to apply, limits to be met, and statistics to compute. Setups can also control printing of hardcopy. Setups saved to memory registers are preserved when the Counter is powered down or disconnected from a power source.

The Save and Recall functions enable faster and easier operation, fewer operator errors, and minimum training.

The **Save** and **Recall** keys allow you to:

- create and save up to 20 different instrument measurement setups into internal non-volatile memory (**SAVE:**).
- recall up to 20 user-selected measurement setups that were previously saved (**RECALL 1, 2, 3, ... 20**). With a total of 21 save/recall registers, there are 20 registers available to you for save/recall operations. The Counter automatically saves the current setup to register 0 (**RECALL 0**) before executing a recall function.
- delete any of the saved setups (**UNSAVE:**).

## Chapter 2 Operating Your Frequency Counter

### Using the Save and Recall Menus

#### To Use the Save Function

The following step-by-step procedure describes how to SAVE a simple measurement setup to quickly get you familiar with the Save function.

You will SAVE the following in register 1 (**SAVE: 1**):

- the Period measurement function,
- the input conditioning parameters:
  - auto trigger to off
  - trigger level to 1.5V
  - input impedance to 50Ω
  - input coupling to DC

**1 Cycle *POWER* key to preset the Counter setup.**

The Counter is now ready to measure the **frequency** of a signal applied to CHANNEL 1 input as indicated by the **Freq** and **Ch1** annunciators.

**2 Press *Other Meas* key until *PERIOD 1* is displayed.**

The Counter is now ready to measure the **period** of a signal applied to CHANNEL 1 input as indicated by the **Period** and **Ch1** annunciators.

**3 Press *Trigger/Sensitivity* key.**

**AUTO TRG: ON** is displayed.

**4 Press any one of the arrow keys.**

**AUTO TRG: OFF** is displayed.

**5 Press *Trigger/Sensitivity* key, or *Enter* key.**

**LEVEL: 0.000v** is displayed.

**6 Using the appropriate arrow keys, set the trigger level to 1.5V.**

## Chapter 2 Operating Your Frequency Counter Using the Save and Recall Menus

- 7 Press **Enter** key to complete the 1.5V entry.
- 8 Press **50Ω/1MΩ** key to set input impedance to 50Ω
- 9 Press **DC/AC** key to set input coupling to DC.
- 10 To save these settings, which make up your measurement setup, simply perform the following steps:
  - a. Press **Save & Print** key.  
**SAVE: NO** is displayed.
  - b. Press the appropriate arrow key until **SAVE: 1** is displayed.
  - c. Press **Enter** key.  
The measurement setup is now saved in register 1. To recall this measurement setup, perform the recall procedure in the following section.

### To Use the Recall Function

This procedure describes how to RECALL the measurement setup you've saved in the previous procedure.

---

**NOTE**

---

You cannot save a setup to register 0 (**RECALL 0**). The Counter automatically saves the current setup to register 0 before executing a recall function. You can, however, recall the setup in the register 0 if you need to, which is the purpose of this "backup" storage register.

- 1 Cycle **POWER** key to preset the Counter.

Note the Counter is set to measure the **frequency** of a signal applied to channel 1 as indicated by the **Freq** and **Ch1** annunciators.

- 2 Press **Recall** key until **RECALL 1** is displayed, and press **Enter** key or let the Counter time out.

Note that the measurement setup has been recalled as indicated by the **Period** and **Ch1** annunciators, and **50Ω** and **DC** LEDs.

Chapter 2 Operating Your Frequency Counter  
Using the Save and Recall Menus

**To Unsave a Measurement Setup**

- 1 To unsave the measurement setup you've saved in the previous procedure, press **Save & Print** key until **UNSAVE: NO** is displayed.
- 2 Press the appropriate arrow keys to select **UNSAVE: 1**, then press **Enter** key.

The measurement setup that was saved in register 1 (**RECALL: 1**) is deleted or unsaved.

**ADDITIONAL INFORMATION ABOUT UNSAVE**

If the **UNSAVE:** display DOES NOT show up after the **SAVE:** display, then no setups have been saved; all registers are empty.

If **UNSAVE:** display is present in the **Save & Print** key menu, then at least one setup has been saved. (To determine how many setups are saved, continuously press the **d** key while **UNSAVE: n** is displayed and count the number of registers that are present.) Perform step 2, below, to delete a measurement setup.

- 1 Suppose there are two registers (1 and 2) that have setups saved in them. To remove these setups, perform the following:
  - a. At the **UNSAVE: 1** display, press **Enter** key.  
**UNSAVE: 2** is displayed, indicating that register 1 has been cleared. To check if the clearing was done, press the **d** key; the “**1**” display should not exist.
  - b. At the **UNSAVE: 2** display, press **Enter** key.  
All registers are cleared when the **UNSAVE** menu item is NOT present in the **Save & Print** key menu.
- 2 Now, suppose in the previous step (2) you wanted to leave register 1 alone, but you want to delete register 2. Perform the following steps:
  - a. At the **UNSAVE: 1** display, press **d** key.  
**UNSAVE: 2** is displayed.
  - b. Press **Enter** key to delete register 2.

---

## Using the Print Menu



### Overview of the Print Menu

The Print menu allows you to:

- enable or disable printing (**PRINT: OFF** or **ON**).
- get help on how to print (**PRT HELP: NO** or **YES**).

### To Use the Print Menu

- 1 Press *Save & Print* key until **PRINT:** is displayed.
- 2 Press any one of the arrow keys, if required, until **PRINT: ON** is displayed.

When PRINT is enabled, the Counter displays and prints the results for each measurement. In addition, if **STATS: ON**, all statistics (that is, standard deviation, mean, maximum, and minimum) will be printed.

---

**NOTE**

---

Printing may slow the update rate of the Counter because the Counter may have to wait for the printer.

- 3 Press *Save & Print* or *Enter* key.  
**PRT HELP: NO** is displayed.
- 4 Press any one of the arrow keys to select **PRT HELP: YES**.
- 5 Press *Enter* key.


The instruction “**CONFIGURE PORT ON UTILITY MENU; REMEMBER TO SAVE SETUP FIRST**” is displayed.

- 6 Save your current setup as shown in the section titled “To Use the Save Function.”
- 7 Refer to the section in this chapter titled “To Configure the RS-232 Serial Port for Printing” for information on how to configure and connect the Counter to a printer.



---

## Using the Utility Menu



### Overview of the Utility Menu

The Utility menu is accessed by holding the **Recall** key and cycling **POWER** key.

The Utility menu allows you to:

- view the firmware revision of your Counter (**REV: n**).
- select and/or display the current GPIB address (**HP- IB: 1, ... 30, or TALK**).
- choose timebase source (**TIMEBAS: AUTO, INT, or EXT**).
- execute several self tests (refer to the paragraph in this section titled “To Run the Self-Test Routines” for details).
- configure the following parameters for the RS-232 port:
  - set the print baud rate (**BAUD: 9600, 19200, 300, 1200, or 2400**).
  - set print parity (**PARITY: OFF, EVEN, or ODD**).
  - set the software pace (**SW PACE: XON or NONE**).
  - set the hardware pace to send data to a serial printer, or to send the Limit-detect output to a computer or controller, via the RS-232 port (**DTR: HIGH, HW PACE, or LIMIT**).
  - change the numerical convention of the Counter’s displayed measurement values. The numeric convention used in the USA separates the integral and fractional portions of a number with a period (a decimal point), and separates groups of three digits in the integer portion with a comma. You can reverse this setting to conform to the numerical convention used in many other countries (**SHOW 9 AS: 9.0 or 9,0**).

### To Set the GPIB Address

Each device on the GPIB must have a unique address. You can set the Counter's address to any value between 0 and 30. The address is set to "3" when the Counter is shipped from the factory.

#### *Selecting Operating Mode (Talk/Listen, Talk-Only)*

The Counter has two GPIB operating modes:

- Addressed (talk/listen)—This mode is for bi-directional communication. The Counter can receive commands and setups from the computer, and can send data and measurement results.

**To select the talk/listen operating mode, set the Counter's GPIB address from 0 to 30.** Refer to the following sub-section titled "Setting the GPIB Address" for instructions on how to select an GPIB address from the front panel.

- Talk-only—In this mode, the Counter can send data to a printer. It cannot receive commands or setups from the computer.

**To select the talk-only operating mode, set the Counter's GPIB mode to "TALK."** Refer to the section titled "To Select the GPIB Talk-Only Mode for Printing" for instructions on how to select talk-only operating mode.

#### *Setting the GPIB Address*

- 1 Press and hold *Recall (Utility)* key, then cycle *POWER* key.

**REV:** *n* is displayed; where "n" represents the numeric firmware revision code.

- 2 Press *Recall (Utility)* key until **HP-IB:** is displayed.

**HP-IB:** **3** is displayed, for example.

- 3 To set the address to 15 (for example), use the appropriate arrow keys to enter the value 15, then press *Enter* key.

---

**NOTE**

---

**BE SURE to press the *Enter* key to complete the numeric entry.**

The address is now stored in *non-volatile* memory, and *does not* change when power has been off or after a remote interface reset.

## Chapter 2 Operating Your Frequency Counter

### Using the Utility Menu

#### To Choose the Timebase Source

The menu choices (**AUTO**, **INT**, and **EXT**) in the timebase menu item (**TIMEBAS:**) allows you to choose to which timebase source the Counter synchronizes its operations.

**AUTO** allows the Counter to be synchronized to the external reference if present, or to the internal 10 MHz oscillator if no external reference is present.

**INT** allows the Counter to be synchronized to the internal 10 MHz oscillator.

**EXT** allows the Counter to be synchronized to an external 1, 5, or 10 MHz house standard (or reference); this reference signal must be connected to the Counter's rear-panel **Ref In** connector.

Perform the following procedures to choose the timebase source:

- 1 Press and hold *Recall (Utility)* key, then cycle *POWER* key.
- 2 Press *Recall (Utility)* key until **TIMEBAS:** is displayed.
- 3 Press any one of the arrow keys until desired choice (that is, **AUTO**, **INT**, or **EXT**) is displayed.

## To Run the Self-Test Routines

### *Overview of the Self-Test Routines*

The Utility menu includes the following three self-test menu items:

- TEST LOOP:
- TST PRINT:
- TEST:

The Counter includes several self-tests. Some self tests are performed at the power-up of the Counter. Some of these self tests can also be invoked from the Utility menu. Other tests can also be invoked from the Utility menu, but a slightly different test is performed. For example, a power-up self test might work regardless of connections to the inputs while a Utility menu self test may require a specific signal to be connected. Some self tests can only be invoked from the Utility menu, for example, the keypad test.

You can specify that the tests should loop forever (**TEST LOOP: ON** or **OFF**) or until any key is pressed.

You can also specify that failure messages be sent to a printer, the RS-232, and the GPIB—if in talk-only (**TST PRINT: ON** or **OFF**).

There are 14 choices for the **TEST:** menu item. They are listed and described in the following text.

**TEST:**      **NO** — no test.

**ALL** — run all tests, except display, keypad and printer tests.

**DISP** — illuminate the indicators and vacuum-fluorescent display (VFD) segments. *Note, this test is not available if **TEST LOOP:** is ON. **TEST LOOP:** must be OFF.*

**CPU** — test processor(s).

**ROM** — checksum the ROM.

**RAM** — test RAM.

## Chapter 2 Operating Your Frequency Counter

### Using the Utility Menu

**EEPROM** — checksum the EEPROM, which is used for non-volatile memory.

**HP-IB** — test GPIB chip.

**QSPI** — test serial hardware control loops.

**FPGA** — internally measure the timebase to test count circuitry.

**FR END** — check front end circuits, either by swinging trigger levels (during power-on test and ALL test) or asking you to connect the timebase output to channel 1.

**MEAS** — make a measurement, either by swinging trigger levels (during power on test and ALL test) or asking you to connect the timebase output to channel 1.

**INTERP** — test interpolators.

**KEYPAD** — request user to press all keys. *Note, this test is not available if **TEST LOOP:** is ON. **TEST LOOP:** must be OFF.*

**PRINT** — send three test lines to a printer via the RS-232. If in talk-only, also send three test lines to a printer via the GPIB.

#### *Example Procedure for Running the Self Test*

- 1 Press and hold *Recall (Utility)* key, then cycle *POWER* key.
- 2 Press *Recall (Utility)* key until **TEST:** is displayed.
- 3 Press any one of the arrow keys to select the desired menu choice in the menu item (for example, the **ALL** menu choice).
- 4 Press *Enter* key to start the test.
- 5 If you are asked to do something, press *Enter* key when you have completed the requested task.

A pass or fail message will be displayed.

### To Configure the RS-232 Serial Port for Printing

Configuring the RS-232 serial port for printing requires that you:

- set the hardware pacing in the DTR (Data Terminal Ready) menu item,
- set the baud rate in the BAUD menu item,
- set the parity type in the PARITY menu item, and
- set the software pacing in the SW PACE menu item.

#### *Setting the Hardware Pacing*

- 1 Press and hold *Recall (Utility)* key, then cycle *POWER* key.
- 2 Press *Recall (Utility)* key until *DTR:* is displayed.
- 3 Press any one of the arrow keys until the desired hardware pacing is displayed.

---

#### **NOTE**

- Choose ***HW PACE*** to use the DTR line for pacing. (***CAUTION: You should only choose this option if your printer and cable support DTR handshaking.***)
- Choose ***HIGH*** to disable hardware pacing.

---

The Counter's talk-only RS-232 port is now set to be the driver for a RS-232 serial printer. The hardware pacing choice is stored in *non-volatile* memory, and *does not* change when power has been off or after a remote interface reset.

## Chapter 2 Operating Your Frequency Counter

### Using the Utility Menu

#### *Setting the Baud Rate*

You can select one of five baud rates for RS-232 operation. The rate is set to 9600 baud when the Counter is shipped from the factory.

- 1 Press *Recall (Utility)* key until **BAUD:** is displayed.
- 2 Press any one of the arrow keys until the desired baud rate is displayed.

The baud rate is stored in *non-volatile* memory, and *does not* change when power has been off or after a remote interface reset.

#### *Setting the Parity*

You can select the parity for RS-232 operation. The Counter is configured for parity off when shipped from the factory.

- 1 Press *Recall (Utility)* key until **PARITY:** is displayed.
- 2 Press any one of the arrow keys until the desired parity is displayed.

The parity choice is stored in *non-volatile* memory, and *does not* change when power has been off or after a remote interface reset.

#### *Setting the Software Pace*

You can select the software pace for RS-232 operation.

- 1 Press *Recall (Utility)* key until **SW PACE:** is displayed.
- 2 Press any one of the arrow keys until the desired software pacing is displayed.

The software pacing choice is stored in *non-volatile* memory, and *does not* change when power has been off or after a remote interface reset.

### To Configure the RS-232 Serial Port for Sending Limit-Detect Output

---

**NOTE**

---

If you cycle power, you will lose everything except saved measurement setups and special parameters stored in non-volatile memory; therefore, make sure you use the Save function of the Counter to retain the measurement setup prior to powering down to set up the Limit-Detect Output line (pin 4) of RS-232 serial connector. Refer to the appropriate section in this chapter for details on how to use Save and Recall.

- 1 **To use the Limit-detect output from the serial port, perform the following steps:**
  - a. Save your measurement setup that includes your Limit Testing choices, by simply pressing the **Save & Print** key and the appropriate arrow keys until **SAVE: 1** is displayed, then **Enter** key to save to register 1.
  - b. Turn off the Counter.
  - c. Press and hold **Recall (Utility)** key, then press **POWER** key.
  - d. Press **Recall (Utility)** key until **DTR:** is displayed.
  - e. Press any one of the arrow keys until **DTR: LIMIT** is displayed.
- 2 **Press Run key.**
- 3 **Press Recall (Utility) key until RECALL 1 is displayed, then wait a few seconds to recall the measurement setup saved in register 1.**

Since your measurement setup included your settings for upper and lower limits, and **LIM TEST:** was set to **ON**, the Counter is now set for limit testing with the Limit-detect output.

If a measurement drifts out of the user-entered limits, the Limit annunciator in the display will light. Also, pin 4 on the RS-232 connector will change state (to a low-voltage RS-232 level) to flag each time a measurement drifts out of the limits. (RS-232 voltage levels swing from  $\pm 12\text{V}$ .)



### To Select the Numerical Convention for the Display

- 1 Press and hold *Recall (Utility)* key, then cycle *POWER* key.
- 2 Press *Recall (Utility)* key until **SHOW 9 AS:** is displayed.
- 3 Press any one of the arrow keys until your menu choice is displayed.

If you choose **SHOW 9 AS: 9.0**, the Counter will display a frequency measurement similar to **12.000,000,000.1 MHz**, for example. Note that the integral portion (12) is separated from the fractional portion of the number by a *period* (or decimal point). This numerical convention is used in the USA.

If you choose **SHOW 9 AS: 9,0**, the Counter will display a frequency measurement similar to **12,000.000.000.1 MHz**, for example. Note that the integral portion (12) is separated from the fractional portion of the number by a *comma*. This numerical convention is used in many other countries.

Your numerical convention choice for the display is stored in *non-volatile* memory, and *does not* change when power has been off or after a remote interface reset.

### To Connect the Counter to a Serial Printer via the RS-232 Port

The RS-232 port on the Counter's rear panel is a 9-pin connector (DB-9, male connector). You can connect the Counter to any printer with a properly configured DTE connector (DB-25). You can use a standard Agilent 24542G or 24542H interface cable.

Connect the Counter to a terminal or printer by simply installing an RS-232 cable (such as an AT Printer Cable—Agilent P/N 24542H cable between the units.

### To Connect the Counter to a Printer via GPIB

You can connect the Counter to a printer via GPIB either with or without a computer. If you connect a computer, you can operate the printer under program control. In the absence of a computer, the Counter, when in talk-only, becomes the controller for the printer.

### To Select the GPIB Talk-Only Mode for Printing

- 1 Press and hold *Recall (Utility)* key, then cycle *POWER* key.
- 2 Press *Recall (Utility)* key until *HP-IB:* is displayed.
- 3 To set the GPIB to talk-only, press the appropriate arrow keys until *HP-IB: TALK* is displayed.

The TALK choice follows 30 and precedes 0 in the set of choices for the GPIB menu item.

---

**NOTE**

---

**BE SURE to press the *Enter* key to complete the numeric entry.**

The talk-only operating mode is now stored in *non-volatile* memory, and *does not* change when power has been off or after a remote interface reset.

## Front Panel Display Messages

There are four types of displays:


- Measurement Result Displays
- Power-Up/Self Test Messages
- Menu Messages
- GPIB Messages

### Measurement Result Displays

**Table 2-3. Measurement Result Displays**

Display Message	Probable Cause
<b>DOING STATS</b>	You have chosen to see a statistics result and the Counter is calculating statistics, but does not have valid statistics results yet.
<sup>1</sup> <b>INTERP FAIL</b>	Interpolator calibration failed on the last measurement; therefore, no valid measurement was taken.
<sup>1</sup> <b>MEAS FAIL</b>	A measurement calibration failed on the last measurement.
<b>NEW TIMEBASE</b>	You have selected the auto reference mode ( <b>TIMEBAS: AUTO</b> ) and the Counter detected that the external reference became invalid <i>during</i> the measurement. Therefore, the current result is not valid, and the Counter switches to using the internal reference.
<b>NO TIMEBASE</b>	You have selected external reference ( <b>TIMEBAS: EXT</b> ) and there is no external reference applied to the rear-panel <b>Ref In</b> connector, or the external signal is not an allowed frequency.
-----	There is no valid measurement available to display. The Counter may be stopped between measurements while in Single mode, and you need to press the <b>Stop/Single</b> key; or trigger level or input conditioning may need adjustment.

<sup>1</sup> If this condition recurs, your Counter may need servicing.



## Chapter 2 Operating Your Frequency Counter

### Front Panel Display Messages

#### Power-Up/Self Test Messages

The following sequence occurs when you turn on the Counter:

- 1 All of the vacuum-fluorescent display segments and the indicators (or LEDs) are illuminated for the power-up test.
- 2 If all tests pass: **SELFTST: PASS** will be displayed. (See NOTE below.)
- 3 **HP-IB AT 3** is displayed, and then the Counter will start taking measurements.

#### NOTE

If there is a failure, each test that fails will display a failure message, and **SELFTST: FAIL** will be displayed. You must press any key in order for the Counter to go on.

Possible individual failure messages are:

<b>FAIL: DISP</b>	display test
<b>FAIL: CPU</b>	processor test
<b>FAIL: ROM</b>	ROM test
<b>FAIL: RAM</b>	RAM test
<b>FAIL: EEPROM</b>	EEPROM test
<b>FAIL: HP-IB</b>	GPIB hardware test
<b>FAIL: QSPI</b>	serial hardware loops test
<b>FAIL: FPGA</b>	count circuit test
<b>FAIL: FR END</b>	front end test
<b>FAIL: MEAS</b>	measurement test
<b>FAIL: INTERP</b>	interpolator test

In addition, the following power-up message may be displayed:

#### **UNCALIBRATED**


This means that at least one type of calibration has NOT been performed.

Chapter 2 Operating Your Frequency Counter  
**Front Panel Display Messages**

**Menu Messages**

**Table 2-4. Menu Messages**

Display Message	Description
<b>(AC COUPLED)</b>	You have selected the VOLT PEAKS function to be measured on a channel which is ac coupled.
<b>BAD CODE</b>	The Counter's calibration is secured and you have entered an incorrect code.
<b>CAL ABORTED</b>	Calibration was aborted because of GPIB or the user pressing a key besides the <b>Enter</b> key.
<b>CAL SECURE</b>	You are in the Calibration menu, and the first menu item indicates that the Counter is secure against calibration.
<b>CAL UNSECURE</b>	You are in the Calibration menu, and the first menu item indicates that the Counter is unsecure for calibration.
<b>CALIBRATING</b>	You have invoked calibration from the Calibration menu item <b>CAL:</b> , and the Counter is currently performing the calibration.
<sup>1</sup> <b>EEPROM FAIL</b>	You have requested that a Counter setting which is stored in the EEPROM ( <b>HP-IB:</b> , <b>BAUD:</b> , <b>PARITY:</b> , <b>SW PACE:</b> , <b>DTR:</b> , <b>SHOW 9 AS:</b> , or <b>CAL:</b> ) be updated, and a hardware failure has resulted.
<b>FAIL, NO MEAS</b>	You have selected <b>SET REF: YES</b> without a valid measurement.
<b>GAIN 1 FAIL</b>	You have invoked the <b>GAIN</b> choice from the Calibration menu item <b>CAL:</b> , and the calibration failed.
<b>GAIN 1 PASS</b>	You have invoked the <b>GAIN</b> choice from the Calibration menu item <b>CAL:</b> , and the calibration passed.
<b>IN REMOTE</b>	You have pressed a key (other than <b>Local</b> ) while in remote.
<b>LOCAL LCKOUT</b>	You have pressed the <b>Local</b> (Save & Print) key while in remote with local lockout.
<b>NO CHANNEL 2</b>	You have pressed the <b>Freq Ch 2</b> key and your Counter does not contain the optional 1.5 GHz or 3.0 GHz RF Input (CHANNEL 2).
<b>NO GATE MENU</b>	You currently have the VOLT PEAKS function selected and requested the Gate & Ext Arm menu.
<b>NO LIM MENU</b>	You currently have the VOLT PEAKS function selected and requested the Upper & Lower or Limit Modes menu.
<b>NO MATH MENU</b>	You currently have the VOLT PEAKS function selected and requested the Scale & Offset menu.



Chapter 2 Operating Your Frequency Counter  
**Front Panel Display Messages**

**Table 2-4. Menu Messages (continued)**

Display Message	Description
<b>NO REGISTERS</b>	There are no registers which can be recalled and you selected the Recall menu.
<b>NO STAT MENU</b>	You currently have the VOLT PEAKS function selected and requested the Stats menu.
<b>NO TRIG MENU</b>	You currently have the VOLT PEAKS function selected and requested the Trigger/Sensitivity menu.
<b>NOT ENTERED</b>	The <b>Enter</b> key was NOT pressed after you changed a numeric parameter. The parameter (for example, <b>SCAL: nnnnn</b> ) was returned to its previous value and must be re-entered. Press the <b>Enter</b> key to save changes made to numeric parameters.  This message will also be displayed when an event (for example, <b>TEST: ALL</b> or <b>SET REF: YES</b> ) or help ( <b>MATH HELP: YES</b> ) is selected, but not invoked with <b>Enter</b> key.
<b>OFFS 1 FAIL</b>	You have invoked the <b>OFFS</b> choice from the Calibration menu item <b>CAL:</b> , and the calibration failed.
<b>OFFS 1 PASS</b>	You have invoked the <b>OFFS</b> choice from the Calibration menu item <b>CAL:</b> , and the calibration passed.
<sup>1</sup> <b>RECALL FAIL</b>	You have requested the Counter to perform a recall (from the Recall menu) and a hardware failure has resulted.
<sup>1</sup> <b>SAVE FAIL</b>	You have requested the Counter to perform a save (from the Save & Print menu) and a hardware failure has resulted.
<b>TB CAL FAIL</b>	You have invoked the <b>TIMEBAS</b> choice from the Calibration menu item <b>CAL:</b> , and the calibration failed.
<b>TB CAL PASS</b>	You have invoked the <b>TIMEBAS</b> choice from the Calibration menu item <b>CAL:</b> , and the calibration passed.

<sup>1</sup> If this condition recurs, your Counter may need servicing.

Chapter 2 Operating Your Frequency Counter  
**Front Panel Display Messages**

**GPIB Messages**

**Table 2-5. GPIB Messages**

Display Message	Description
<sup>1</sup> <b>HP-IB +nnnn</b>	You have generated the GPIB error corresponding to the indicated error number. Refer to Chapter 5, “Errors,” in the Programming Guide for a list of the error descriptions.
<sup>1</sup> <b>HP-IB -nnn</b>	You have generated the GPIB error corresponding to the indicated error number. Refer to Chapter 5, “Errors,” in the Programming Guide for a list of the error descriptions.

<sup>1</sup> +nnnn and -nnn represent GPIB error code numbers that would actually be displayed.

**Preset Values After Power-up and \*RST**

**Preset Values for Functions Accessible Via Front Panel or GPIB**

**Table 2-6. Agilent 53181A Preset Values**


Description	In Save/Recall	Value at *RST (GPIB Reset)	Value at Power- Up	In Non-Volatile Memory
<b>Function-Select Parameters</b>				
Measurement function	yes	FREQ1	FREQ1	no
<b>Frequency, Period, and Ratio Arming Parameters</b>				
Frequency arm	yes	———	TIME	no
Frequency start arm	yes	IMMediate	———	no
Frequency stop arm	yes	TIMer	———	no
Frequency stop arm digits	yes	4	4	no
Frequency gate time	yes	100.E-3s	100.E-3s	no
Frequency ext start arm slope	yes	POS	POS	no
Frequency ext stop arm	yes	———	AUTO	no
<b>Input Parameters</b>				
Channel 1 input coupling	yes	AC	AC	no
Channel 1 input impedance	yes	1E+6 Ohms	1E+6 Ohms	no
Channel 1 input attenuation	yes	X1	X1	no
Channel 1 input filter	yes	OFF	OFF	no
<b>Display Parameters</b>				
Display digits masked	yes	0	0	no
Display blank	no	disabled	disabled	no
Display mode (result/menu)	no	results	results	no
<b>Trigger/Sensitivity Parameters</b>				



Chapter 2 Operating Your Frequency Counter  
**Preset Values After Power-up and \*RST**

**Table 2-6. Agilent 53181A Preset Values (continued)**

Description	In Save/Recall	Value at *RST (GPIB Reset)	Value at Power- Up	In Non-Volatile Memory
Channel 1 auto trigger	yes	ON	ON	no
Channel 1 trigger level (volts)	yes	0.000V <sup>1</sup>	0.000V <sup>1</sup>	no
Channel 1 trigger level (percent)	yes	50%	50%	no
Channel 1 trigger slope	yes	POS	POS	no
Channel 1 sensitivity	yes	100%	HIGH	no
<b>Measurement Control Parameters</b>				
Run/Single selection	yes	<b>SINGLE</b>	<b>RUN</b> <sup>2</sup>	no
<b>Math Operation Parameters</b>				
Math on/off	yes	OFF	OFF	no
Scale	yes	1.000000	1.000000	no
Offset	yes	0.0000000000	0.0000000000	no
<b>Limits Parameters</b>				
Limit test on/off	yes	OFF	OFF	no
On fail stop/go on	yes	GO ON	GO ON	no
Lower limit	yes	0.0000000000	0.0000000000	no
Upper limit	yes	0.0000000000	0.0000000000	no
Limit display number/graph	yes	NUMBER	NUMBER	no
<b>Stats Parameters</b>				
Stats on/off	yes	OFF	OFF	no
Stats measurement count, N	yes	100	100	no
Display measurement/stats	yes	MEAS	MEAS	no
Stats use all/in limits	yes	USE ALL	USE ALL	no
On-single measurement count	yes	1 (AUTO OFF)	1 (AUTO OFF)	no
<b>Print Parameters</b>				



Chapter 2 Operating Your Frequency Counter  
**Preset Values After Power-up and \*RST**

**Table 2-6. Agilent 53181A Preset Values (continued)**

Description	In Save/Recall	Value at *RST (GPIB Reset)	Value at Power- Up	In Non-Volatile Memory
Printing on/off	yes	OFF	OFF	no
<b>Timebase Parameters</b>				
Timebase auto/internal/external	no	AUTO	AUTO	no
<b>Expected Frequency Parameters</b>				
Channel 1 expected frequency	no	_____ <sup>3</sup>	_____ <sup>3</sup>	no
Channel 2 expected frequency	no	_____ <sup>3</sup>	_____ <sup>3</sup>	no
<b>Auto-Frequency Parameters</b>				
Channel 1 auto-frequency on/off	no	ON	ON	no
Channel 2 auto-frequency on/off	no	ON	ON	no
<b>Trigger Calibration Parameters</b>				
Channel 1 trigger offset cal	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (2048)
Channel 1 trigger gain cal	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (1700)
<b>Utility Menu Parameters</b>				
Option Timebase cal	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (2048)
GPIB address	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (3)
Digit separator (radix)	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (USA STYLE)
Baud rate, (RS-232)	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (9600)
Parity, (RS-232)	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (OFF)
Pacing, (RS-232)	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (XON)
DTR, (RS-232)	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (DTR_HIGH)
<b>Calibration Security Parameters</b>				
Secure state	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (SECURE)
Security code	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (53181)

## Chapter 2 Operating Your Frequency Counter

### Preset Values After Power-up and \*RST

**Table 2-6. Agilent 53181A Preset Values (continued)**

Description	In Save/Recall	Value at *RST (GPIB Reset)	Value at Power- Up	In Non-Volatile Memory
Calibration count	no	_____ <sup>4</sup>	_____ <sup>4</sup>	yes, (0)

<sup>1</sup> At power-up, the trigger level is defaulted. The default value is shown in the table. The Counter retains this value until the first auto-trigger cycle runs. Since the Counter powers up on Run mode with auto-trigger ON, the auto-trigger cycle runs almost immediately. The default value is overwritten by a measured result almost immediately.

At \*RST, the trigger level variable is defaulted. The default value is shown in the table. Same as for power-up, the Counter retains this value until the first auto-trigger cycle runs. However, on \*RST, the Counter is set up in Single mode, (not Run mode), with auto-trigger ON. The auto-trigger cycle runs only on initiation of a measurement. The default value for the variable persists until overwritten by a measured result, but it may be a long time before you request a measurement; therefore, it may be a long time that the default value persists.

<sup>2</sup> At power-up, you can bring up the Counter either in the Utility menu, or in the results display. The default behavior of the Run/Single variable differs according to that choice.

When the Counter powers up in the result display, it powers up in Run mode and begins making measurements immediately.


The Counter does not make measurements when the Utility menu is selected. (This is to reduce confusion while the user configures major attributes of the instrument.) When you power up on the Utility menu, the Counter is in Single. Upon exit of the Utility menu, the Counter transitions to Run automatically.

<sup>3</sup> At \*RST and at power-up, this value is undefined. The frequency-estimation routine, ("auto-frequency" routine), is enabled. When you select auto-frequency OFF, and provide a value, the variable takes on that value.

<sup>4</sup> Fundamental instrument settings are stored in non-volatile RAM. These settings persist even if the Counter is powered down and back up again. They persist if the Counter is reset over GPIB with \*RST. You can change these settings, and the changed value is stored so that it is unaffected if the Counter is powered down or reset over GPIB with \*RST.

The default values for these special features are indicated in the table. The default values are used when new EPROMs are installed; they remain in effect until you overwrite them.

An example is the trigger calibration setting. Calibration values are defaulted until calibration is performed at the factory. Another example is the RS-232 BAUD rate. BAUD rate is defaulted until you pick a different rate.



Chapter 2 Operating Your Frequency Counter  
**Preset Values After Power-up and \*RST**

**Preset Values for Functions Accessible Via GPIB Only**

**Table 2-7. Agilent 53181A Preset Values—Accessible Via GPIB Only**

Description	In Save/Recall	Value at *RST (GPIB Reset)	Value at Power- Up	In Non-Volatile Memory
<b>Arming Parameters</b>				
Frequency ext stop arm slope	yes	NEG	NEG	no
<b>Math, Limit Parameters</b>				
Math, limit-test recalculate	yes	<b>OFF</b>	<b>ON</b>	no
Reset limit-test fail count on INITiate	yes	ON	ON	no
<b>Statistics Parameters</b>				
Statistics type	yes	MEAN	MEAN	no
<b>Miscellaneous Measurement Parameters</b>				
Interpolator calibration on/off	no	ON	ON	no
Monitor external timebase	no	TRUE	TRUE	no
<b>Status Reporting Parameters</b>				
Event status enable	no	_____	0	no
Service request enable	no	_____	0	no
*OPC	no	disabled	disabled	no
OSR enable	no	_____	0	no
OSR positive transition filter	no	_____	1809	no
OSR negative transition filter	no	_____	0	no
QSR enable	no	_____	0	no
QSR positive transition filter	no	_____	17701	no
QSR negative transition filter	no	_____	0	no
Error queue	no	_____	cleared	no

Chapter 2 Operating Your Frequency Counter  
**Preset Values After Power-up and \*RST**

**Table 2-7. Agilent 53181A Preset Values—Accessible Via GPIB Only (continued)**

Description	In Save/Recall	Value at *RST (GPIB Reset)	Value at Power- Up	In Non-Volatile Memory
<b>Miscellaneous GPIB Parameters</b>				
CONFigure? response	no	_____	undefined	no
Device trigger definition	yes	INIT	INIT	no
Key queue	no	_____	cleared	no
Macros	no	disabled	disabled	no
Response format	yes	ASCii	ASCii	no
READ, FETCh function memory	no	_____	_____	no

---

## Common Questions

### **Why is Stats result not available yet?**

Your Counter has not completed N measurements yet.

If you are filtering (Stats menu, **USE: IN LIMIT**), then stats result will not be available until N *in-limit* measurements are made.

If you are using the **ON SINGLE: N** measurements, make sure you have pressed the **Single** or **Run** key.

The instrument is collecting measurements if the **Gate** annunciator is flashing on and off.

### **Why won't printer work?**

Go to the Utility menu and set up serial port.

### **Why did Counter stop measuring?**

- Did you set the Counter to stop on limits?
- Are all measurements outside the limits?

### **Why did Counter go to its default state after I set up my RS-232 port?**

- Did you save your state before you cycled power?
- Did you restore your state after configuring the port?

### **Counter's numeric display does not follow the numerical convention for my country.**

- Go to the Utility menu and change the numerical convention to be displayed (use the **SHOW 9 AS:** menu item).

---

3

---

Specifications

Chapter 3 Specifications  
Introduction

## Introduction

The specifications of the Agilent 53181A Frequency Counter are shown in the following table.

### Instrument Inputs

#### Channel 1 Input Specifications

##### Frequency Range

DC Coupled:	DC to 225 MHz
AC Coupled:	1 MHz to 225 MHz (50 $\Omega$ ) 30 Hz to 225 MHz (1 M $\Omega$ )
FM Tolerance:	25%

##### Voltage Range and Sensitivity (Sinusoid)<sup>1</sup>

DC to 100 MHz:	20 mVrms to $\pm 5$ V ac + dc (75 mVrms with optional rear connectors) <sup>2</sup>
100 MHz to 200 MHz:	30 mVrms to $\pm 5$ V ac + dc (75 mVrms with optional rear connectors) <sup>2</sup>
200 MHz to 225 MHz:	40 mVrms to $\pm 5$ V ac + dc (75 mVrms with optional rear connectors) <sup>2</sup>

##### Voltage Range and Sensitivity (Single-Shot Pulse)<sup>1</sup>


4.5 ns to 10 ns Pulse Width:	100 mVpp to 10 Vpp (150 mVpp with optional rear connectors) <sup>2</sup>
>10 ns Pulse Width:	50 mVpp to 10 Vpp (100 mVpp with optional rear connectors) <sup>2</sup>

##### Trigger Level<sup>2</sup>

Range:	$\pm 5.125$ V
Accuracy:	$\pm (15$ mV + 1% of trigger level)
Resolution:	5 mV

##### Damage Level

0 to 3.5 kHz, 1 M $\Omega$	50 $\Omega$ 5 Vrms
3.5 kHz to 100 kHz, 1 M $\Omega$	350 V dc + ac pk
>100 kHz, 1 M $\Omega$	350 V dc + ac pk linearly derated to 5 Vrms
	50 $\Omega$ 5 Vrms



<sup>1</sup> Values shown are for X1 attenuator setting. Multiply all values by 10 (nominal) when using the X10 attenuator setting. Note that it may be necessary to recalibrate the input offset in the application environment (especially at high temperature) to achieve maximum sensitivity.

<sup>2</sup> When ordered with optional rear terminals, the Channel 1 input is active on both the front and rear of the counter though the specifications provided only apply to the rear terminal. Performance for the front terminal is degraded, but may be improved by terminating the rear terminal into 50  $\Omega$ .

#### Channel 1 Input Characteristics

Impedance:	1 M $\Omega$ or 50 $\Omega$
1 M $\Omega$ Capacitance:	30 pF
Coupling:	AC or DC
Low-Pass Filter:	100 kHz (or disabled) -20 dB at > 1 MHz
Input Sensitivity:	Selectable between Low, Medium, or High (default). Low is approximately 2x High Sensitivity.

Trigger Slope: Positive or Negative

##### Auto Trigger Level

Range:	0 to 100% in 10% steps
Frequency:	> 100 Hz
Input Amplitude:	> 100 mVpp (No amplitude modulation)

##### Attenuator

Voltage Range:	x10
Trigger Range:	x10



## Chapter 3 Specifications

### Introduction

#### Instrument Inputs (Continued)

---

##### Channel 2 Input Specifications<sup>3, 4</sup>

###### Frequency Range

Opt. 015	100 Mhz to 1.5 Ghz
Opt. 030	100 MHz to 3 GHz
Opt. 050	200MHz to 5 GHz
Opt. 124	200 MHz to 12.4 GHz

###### Power Range and Sensitivity (Sinusoid)

###### Option 015

100 MHz to 1.5 GHz: -27 dBm to +19 dBm

###### Option 030

100 MHz to 2.7 GHz: -27 dBm to +19 dBm  
2.7 GHz to 3 GHz: -21 dBm to +13 dBm

###### Option 050

200 MHz to 5 GHz: -23 dBm to +13 dBm

###### Option 124

200 MHz to 12.4 GHz: -23 dBm to +13 dBm

###### Damage Level:

Option 015, 030	5 Vrms
Option 050, 124	+25 dBm

---

##### External Arm Input Specifications

###### Signal Input Range:

TTL compatible

###### Timing Restrictions:

Pulse Width:	> 50 ns
Transition Time:	< 250 ns
Start-to-Stop Time:	> 50 ns

Damage Level: 10 Vrms

---

##### Channel 2 Input Characteristics

Impedance:	50 $\Omega$
Coupling:	AC
VSWR:	< 2.5:1

---

##### External Arm Input Characteristics

Impedance:	1 k $\Omega$
Input Capacitance:	17 pF
Start Slope:	Positive or Negative
Stop Slope:	Positive or Negative

###### Notes:

External Arm available for all measurements except Peak Volts.

External Arm is referred to as External Gate for some measurements.

<sup>3</sup> Channel 2 is available as an option.

<sup>4</sup> When ordered with optional rear terminals, the Channel 2 connector on the front panel for Options 015 or 030 will be removed. There is no degradation in specifications for this input. Option 050 and Option 124 input connectors are available on the front panel only.

Chapter 3 Specifications  
Introduction

**Time Base**

**Internal Time Base Stability**

	Standard (0° to 50° C)	Medium Stability Oven (Option 001)	High Stability Oven (Option 010)	Ultra High Stability Oven (Option 012)
<b>Temperature Stability:</b> (referenced to 25° C)	$< 5 \times 10^{-6}$	$< 2 \times 10^{-7}$	$< 2.5 \times 10^{-9}$	$< 2.5 \times 10^{-9}$
<b>Aging Rate</b> (after 30 days) Per Day: Per Month: Per Year:	$< 3 \times 10^{-7}$	$< 4 \times 10^{-8}$ $< 2 \times 10^{-7}$	$< 5 \times 10^{-10}$ $< 1.5 \times 10^{-8}$	$< 1 \times 10^{-10}$ $< 3 \times 10^{-9}$ $< 2 \times 10^{-8}$
<b>Turn-on stability vs. time:</b> (in 30 minutes)		$< 2 \times 10^{-7}$ (referenced to 2 hours)	$< 5 \times 10^{-9}$ (referenced to 24 hours)	$< 5 \times 10^{-9}$ (referenced to 24 hours)
<b>Calibration:</b>	Manual Adjust	Electronic	Electronic	Electronic

Note that power to the time base is maintained when the counter is placed in standby via the front panel switch. The internal fan will continue to operate under this condition, to maintain long-term instrument reliability.

**External Time Base Input Specifications**

Voltage Range: 200 mVrms to 10 Vrms  
Damage Level: 10 Vrms

**External Time Base Input Characteristics**

Threshold: 0 V  
Impedance: 1 k $\Omega$   
Input Capacitance: 23 pF  
Frequency: 1 MHz, 5 MHz or 10 MHz  
(automatic selection)

**Internal vs. External Time Base Selection:**

Manual: Select Internal or External  
Automatic: Internal used when External not present  
(default)

**Time Base Output Specifications**

Output Frequency: 10 MHz  
Voltage:  $> 1$  Vpp into 50  $\Omega$   
(centered around 0 V)

Chapter 3 Specifications  
Introduction

**Measurement Specifications**

**Frequency, Period**

**Channel 1 Range:** 0.1 Hz to 225 MHz 4.44 ns to 10 s

**Channel 2 Range:**

Option 015	100 Mhz to 1.5 Ghz	0.67 ns to 10 ns
Option 030	100 MHz to 3 GHz	0.33 ns to 10 ns
Option 050	200 MHz to 5 GHz	0.2 ns to 5 ns
Option 124	200 MHz to 12.4 GHz	80 ps to 5 ns

(Period 2 selectable only via the GPIB interface)

**For Automatic or External Arming:**

(and signals < 100 Hz using Timed Arming)

**LSD Displayed:**

$$\left( \frac{t_{res}}{Gate\ Time} \right) \times \begin{matrix} Frequency \\ or \\ Period \end{matrix}$$

**RMS Resolution:**

$$\left( \frac{\sqrt{t_{res}^2 + (2 \times Trigger\ Error)^2}}{Gate\ Time} \right) \times \begin{matrix} Frequency \\ or \\ Period \end{matrix}$$

$t_{res}$ : 650 ps typical<sup>5</sup>

For Automatic Arming:  $Gate\ Time = \frac{N}{Frequency}$

where  $N =$  1 for Ch1 Frequency < 1 MHz  
4 for Ch1 Frequency > 1 MHz  
128 for Ch2

**Systematic Uncertainty:**  $\left( \pm Time\ Base\ Error \pm \frac{t_{acc}}{Gate\ Time} \right) \times \begin{matrix} Frequency \\ or \\ Period \end{matrix}$

$t_{acc}$ : 350 ps typical  
1.25 ns worst case

**Trigger:** Default setting is Auto Trigger at 50%

**For Time or Digits Arming:**

**LSD Displayed:**

$$\left( \frac{2\sqrt{2} \times t_{res}}{Gate\ Time \times \sqrt{Number\ or\ Samples}} + \frac{t_{jitter}}{Gate\ Time} \right) \times \begin{matrix} Frequency \\ or \\ Period \end{matrix}$$

**RMS Resolution:**

$$\left( \frac{4 \times \sqrt{t_{res}^2 + (2 \times Trigger\ Error)^2}}{Gate\ Time \times \sqrt{Number\ or\ Samples}} + \frac{t_{jitter}}{Gate\ Time} \right) \times \begin{matrix} Frequency \\ or \\ Period \end{matrix}$$

$t_{res}$ : 500 ps typical<sup>5</sup>  
 $t_{jitter}$ : 50 ps typical<sup>5</sup>

$Number\ of\ Samples =$   
 $\frac{Gate\ Time \times Frequency}{Gate\ Time \times 200,000}$  (Frequency < 200 kHz)  
 $\frac{Gate\ Time \times Frequency}{Gate\ Time \times 200,000}$  (Frequency > 200 kHz)

**Systematic Uncertainty:**  $\left( \pm Time\ Base\ Error \pm \frac{t_{acc}}{Gate\ Time} \right) \times \begin{matrix} Frequency \\ or \\ Period \end{matrix}$

$t_{acc}$ : 100 ps typical  
300 ps worst case

**Trigger:** Default setting is Auto Trigger at 50%


The following graphs may also be used to compute errors for Period Measurements. To find the Period error ( $\Delta P$ ), calculate the frequency of the input signal ( $F = \frac{1}{P}$ ) and find the frequency error ( $\Delta F$ ) from the chart. Then, calculate the period error as:  $\Delta P = \left( \frac{\Delta F}{F} \right) \times P$

Chapter 3 Specifications  
Introduction


Measurement Specifications (Continued)

Agilent 53131A—Worst Case RMS Resolution

Automatic or External Arming:



Time or Digit Arming:



The preceding graphs do not reflect the effects of trigger error. To place an upper bound on the added effect of this error term, determine the frequency error from the appropriate graph and add a trigger error term as follows:

Automatic or External Arming

$$\text{Frequency Error} + \left( \frac{\sqrt{2} \times \text{Trigger Error}}{\text{Gate Time}} \right) \times \begin{matrix} \text{Frequency} \\ \text{or} \\ \text{Period} \end{matrix}$$

Time or Digit Arming


$$\text{Frequency Error} + \left( \frac{4 \times \sqrt{2} \times \text{Trigger Error}}{\text{Gate Time} \times \sqrt{\text{Number of Samples}}} \right) \times \begin{matrix} \text{Frequency} \\ \text{or} \\ \text{Period} \end{matrix}$$

Chapter 3 Specifications  
Introduction


Measurement Specifications (Continued)

Agilent 53132A—Worst Case RMS Resolution

Automatic or External Arming:



Time or Digit Arming:



The preceding graphs do not reflect the effects of trigger error. To place an upper bound on the added effect of this error term, determine the frequency error from the appropriate graph and add a trigger error term as follows:

Time or Digit Arming

$$\text{Frequency Error} + \left( \frac{4 \times \sqrt{2} \times \text{Trigger Error}}{\text{Gate Time} \times \sqrt{\text{Number of Samples}}} \right) \times \begin{matrix} \text{Frequency} \\ \text{or} \\ \text{Period} \end{matrix}$$

Automatic or External Arming

$$\text{Frequency Error} + \left( \frac{\sqrt{2} \times \text{Trigger Error}}{\text{Gate Time}} \right) \times \begin{matrix} \text{Frequency} \\ \text{or} \\ \text{Period} \end{matrix}$$

Chapter 3 Specifications  
Introduction

**Measurement Specifications (Continued)**

---

**Frequency Measurement Example:**

Given an Agilent 53132A with a High Stability Oven that was calibrated 3 days ago, measure a 15 MHz square wave signal (which has negligible trigger error) with a 1 second gate time. Compute the measurement error to within 2-sigma confidence.

*Measurement Error = Systematic Uncertainty  $\pm 2 \times$  RMS Resolution*

$$= \left( \left( \pm \text{Time Base Error} \pm \frac{t_{acc}}{\text{Gate Time}} \right) \pm 2 \times \left( \frac{4 \times \sqrt{t_{res}^2 + (2 \times \text{Trigger Error})^2}}{\text{Gate Time} \times \sqrt{\text{Number of Samples}}} + \frac{t_{jitter}}{\text{Gate Time}} \right) \right) \times \text{Frequency}$$

*Number of Samples = 200,000 since Frequency is greater than 200kHz and gate time equals 1 second*

*Time Base Error = Temperature Stability + 3 Days  $\times$  Daily Aging Rate*

$$= 2.5 \times 10^{-9} + 3 \times (5 \times 10^{-10})$$

$$= 4.0 \times 10^{-9}$$

$$\text{Measurement Error} = \left( \left( \pm 4.0 \times 10^{-9} \pm \frac{1 \times 10^{-11} \text{ s}}{1 \text{ s}} \right) \pm 2 \times \left( \frac{4 \times \sqrt{(225 \times 10^{-12} \text{ s})^2 + (2 \times 0)}}{1 \text{ s} \times \sqrt{200,000}} + \frac{3 \times 10^{-12} \text{ s}}{1 \text{ s}} \right) \right) \times 15 \text{ MHz}$$

$$= (\pm 4.0 \times 10^{-9} \pm 2 \times (2.01 \times 10^{-12} + 3 \times 10^{-12})) \times 15 \text{ MHz}$$

$$= (\pm 4.0 \times 10^{-9} \pm 1 \times 10^{-11}) \times 15 \text{ MHz}$$

$$= \pm 60.2 \text{ mHz}$$

Which is to say that the Agilent 53132A would display results in the range 15 MHz  $\pm$  60.2 mHz. Note however that the dominant error is the Time Base Error. If an even higher stability time base is available or if the instrument can be source locked to the 15 MHz signal, then this error term can be substantially reduced. The measurement resolution under these conditions is  $\pm 75$   $\mu$ Hz (1 sigma) which determines the number of digits displayed.

Chapter 3 Specifications  
Introduction

Measurement Specifications (Continued)

Time Interval

Measurement is specified over the full signal ranges<sup>7</sup> of Channels 1 and 2.

Results Range: -1 ns to 10<sup>5</sup> s

LSD: 

53131A	53132A
500 ps	150 ps

RMS Resolution:  $\sqrt{t_{res}^2 + \text{Start Trigger Error}^2 + \text{Stop Trigger Error}^2}$   
 $t_{res}$ 

53131A	53132A
750 ps	300 ps

Systematic Uncertainty:  $\pm(\text{Time Base Error} \times TI) \pm \text{Trigger Level Timing Error} \pm 1.5 \text{ ns Differential Channel Error (Agilent 53131A)}$   
 $\pm 900 \text{ ps Differential Channel Error (Agilent 53132A)}$

Time Interval Delay

After a Time Interval Measurement has begun by satisfying the trigger conditions on Channel 1, the instrument will wait for the user-entered delay time to elapse before the end-of-measurement trigger will be accepted on Channel 2. Please refer to Measurement Arming for additional information.

Frequency Ratio:  $\frac{\text{Ch2}}{\text{Ch1}}$   $\frac{\text{Ch1}}{\text{Ch3}}$   $\frac{\text{Ch2}}{\text{Ch1}}$   $\frac{\text{Ch3}}{\text{Ch1}}$

Measurement is specified over the full signal range of each input.

Results Range: 10<sup>-10</sup> to 10<sup>11</sup>

'Auto' Gate Time: 100 ms (or sufficient cycles on Channel 2 or 3 to make a valid measurement, whichever is longer)

LSD:

$$\text{Ratio } 1/2 : \frac{1}{\text{Ch2 Freq} \times \text{Gate Time}}$$

$$\text{Ratio } 1/3 : \frac{1}{\text{Ch3 Freq} \times \text{Gate Time}}$$

$$\text{Ratio } 2/1 : \frac{\text{Ch2 Freq}}{(\text{Ch1 Freq})^2 \times \text{Gate Time}}$$

$$\text{Ratio } 3/1 : \frac{\text{Ch3 Freq}}{(\text{Ch1 Freq})^2 \times \text{Gate Time}}$$

RMS Resolution:

$$\text{Ratio } 1/2 : \frac{2 \times \sqrt{1 + (\text{Ch1 Freq} \times \text{Ch2 Trigger Error})^2}}{\text{Ch2 Freq} \times \text{Gate Time}}$$

$$\text{Ratio } 1/3 : \frac{2 \times \sqrt{1 + (\text{Ch1 Freq} \times \text{Ch3 Trigger Error})^2}}{\text{Ch3 Freq} \times \text{Gate Time}}$$

$$\text{Ratio } 2/1 : \frac{2 \times \text{Ch2 Freq} \times \sqrt{1 + (\text{Ch1 Freq} \times \text{Ch2 Trigger Error})^2}}{(\text{Ch1 Freq})^2 \times \text{Gate Time}}$$

$$\text{Ratio } 3/1 : \frac{2 \times \text{Ch3 Freq} \times \sqrt{1 + (\text{Ch1 Freq} \times \text{Ch3 Trigger Error})^2}}{(\text{Ch1 Freq})^2 \times \text{Gate Time}}$$

To minimize relative phase measurement error, connect the higher frequency signal to Channel 1 when possible.

<sup>7</sup> See Specifications for Pulse Width and Rise/Fall Time measurements for additional restrictions on signal timing characteristics.

Chapter 3 Specifications  
Introduction

**Measurement Specifications (Continued)**

**Pulse Width**

Measurement is specified over the full signal range of Channel 1. The width of the opposing pulse must be greater than 4 ns (e.g., when measuring the positive pulse width, the negative pulse width must be greater than 4 ns).

**Pulse Selection:** Positive or Negative  
**Trigger:** Default setting is Auto Trigger<sup>8</sup> at 50%  
**Results Range:** 5 ns to 10<sup>5</sup> s

**LSD:**

<b>53131A</b>	<b>53132A</b>
500 ps	150 ps

**RMS Resolution:**  $\sqrt{t_{res}^2 + Start\ Trigger\ Error^2 + Stop\ Trigger\ Error^2}$

$t_{res}$  **53131A** **53132A**  
 750 ps 300 ps

**Systematic Uncertainty:**  
 $\pm (Time\ Base\ Error \times Pulse\ Width) \pm Trigger\ Level\ Timing\ Error \pm 1.5\ ns\ Differential\ Channel\ Error\ (Agilent\ 53131A)$   
 $\pm 900\ ps\ Differential\ Channel\ Error\ (Agilent\ 53132A)$

**Rise/Fall Time**

Measurement is specified over the full signal ranges of Channel 1. The interval between the end of one edge and start of a similar edge must be greater than 4 ns. (e.g., when measuring a rising edge, 4 ns must elapse between the 90% point of one rising edge and the 10% point of the next rising edge).

**Edge Selection:** Positive or Negative  
**Trigger:** Default setting is Auto Trigger<sup>8</sup> at 10% and 90%  
**Results Range:** 5 ns to 10<sup>5</sup> s

**LSD:**

<b>53131A</b>	<b>53132A</b>
500 ps	150 ps

**RMS Resolution:**  $\sqrt{t_{res}^2 + Start\ Trigger\ Error^2 + Stop\ Trigger\ Error^2}$

$t_{res}$  **53131A** **53132A**  
 750 ps 300 ps

**Systematic Uncertainty:**  
 $\pm (Time\ Base\ Error \times Transition\ Time) \pm Trigger\ Level\ Timing\ Error \pm 1.5\ ns\ Differential\ Channel\ Error\ (Agilent\ 53131A)$   
 $\pm 900\ ps\ Differential\ Channel\ Error\ (Agilent\ 53132A)$

**Phase**

Measurement is specified over the full signal range of Channels 1 and 2.

**Results Range:** -180° to +360°

**RMS Resolution:**  $\sqrt{(t_{res}^2 + (2 \times Trigger\ Error^2)) \times \left(1 + \left(\frac{Phase}{360^\circ}\right)^2\right)} \times Frequency \times 360^\circ$

$t_{res}$  **53131A** **53132A**  
 750 ps 300 ps

**Systematic Uncertainty:**  $(\pm Trigger\ Level\ Timing\ Error \pm 1.5\ ns\ Differential\ Channel\ Error) \times Frequency \times 360^\circ\ (Agilent\ 53131A)$   
 $(\pm Trigger\ Level\ Timing\ Error \pm 900\ ps\ Differential\ Channel\ Error) \times Frequency \times 360^\circ\ (Agilent\ 53132A)$

<sup>8</sup> Restrictions noted on page 3-2 for Auto Trigger apply to the proper operation of these measurements. The Peak Volts measurement is used to determine the signal amplitude and inaccuracies from this, noted on page 3-11, should be included in calculating the Trigger Level Timing Error.



## Chapter 3 Specifications

### Introduction

#### Measurement Specifications (Continued)

---

##### Duty Cycle

Measurement is specified over the full signal range of Channel 1. However, both the positive and negative pulse widths must be greater than 4 ns.

**Results Range:** 0 to 1 (e.g. 50% duty cycle would be displayed as .5)

**RMS Resolution:**  $\sqrt{(t_{res}^2 + (2 \times \text{Trigger Error}^2)) \times (1 + \text{Duty Cycle}^2) \times \text{Frequency}}$

	<b>53131A</b>	<b>53132A</b>
$t_{res}$	750 ps	300 ps

---

##### Totalize

Measurement is specified over the full signal range of Channel 1.

**Results Range:** 0 to  $10^{15}$

**Resolution:**  $\pm 1$  count

---

##### Peak Volts

Measurement is specified on Channels 1 and 2 for DC signals; or for AC signals of frequencies between 100 Hz and 30 MHz with peak-to-peak amplitude greater than 100 mV. (The measurement will continue to operate up to 225 MHz, though results are for indication only.)

**Results Range:** -5.1 V to +5.1 V

**Resolution:** 10 mV

**Systematic Uncertainty for AC signals:** 25 mV + 10% of V

**for DC signals:** 25 mV + 2% of V


Use of the input attenuator multiplies all voltage specifications (input range, results range, resolution and systematic uncertainty) by a nominal factor of 10. For example with AC signals, the Systematic Uncertainty becomes: 250 mV + 10% of V.

Chapter 3 Specifications  
Introduction


Measurement Specifications (Continued)

Worst Case RMS Resolution

Automatic or External Arming:



Time or Digit Arming:



The preceding graphs do not reflect the effects of trigger error. To place an upper bound on the added effect of this error term, determine the frequency error from the appropriate graph and add a trigger error term as follows:

<p><b>Automatic or External Arming</b></p> $\text{Frequency Error} + \left( \frac{\sqrt{2} \times \text{Trigger Error}}{\text{Gate Time}} \right) \times \frac{\text{Frequency}}{\text{or Period}}$	<p><b>Time or Digit Arming</b></p> $\text{Frequency Error} + \left( \frac{4 \times \sqrt{2} \times \text{Trigger Error}}{\text{Gate Time} \times \sqrt{\text{Number of Samples}}} \right) \times \frac{\text{Frequency}}{\text{or Period}}$
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## Chapter 3 Specifications

### Introduction

### Measurement Specifications (Continued)

---

#### Frequency Measurement Example:

Given an Agilent 53181A with a High Stability Oven that was calibrated 3 days ago, measure a 15 MHz square wave signal (which has negligible trigger error) with a 1 second gate time. Compute the measurement error to within 2-sigma confidence.

*Measurement Error = Systematic Uncertainty ± 2 × RMS Resolution*

$$= \left( \left( \pm \text{Time Base Error} \pm \frac{t_{acc}}{\text{Gate Time}} \right) \pm 2 \times \left( \frac{4 \times \sqrt{t_{res}^2 + (2 \times \text{Trigger Error}^2)}}{\text{Gate Time} \times \sqrt{\text{Number of Samples}}} + \frac{t_{jitter}}{\text{Gate Time}} \right) \right) \times \text{Frequency}$$

*Number of Samples = 200,000 since Frequency is greater than 200kHz and gate time equals 1 second*

*Time Base Error = Temperature Stability + 3 Days × Daily Aging Rate*

$$= 2.5 \times 10^{-9} + 3 \times (5 \times 10^{-10})$$

$$= 4.0 \times 10^{-9}$$

$$\text{Measurement Error} = \left( \left( \pm 4.0 \times 10^{-9} \pm \frac{1 \times 10^{-10} \text{ s}}{1 \text{ s}} \right) \pm 2 \times \left( \frac{4 \times \sqrt{(500 \times 10^{-12} \text{ s})^2 + (2 \times 0)}}{1 \text{ s} \times \sqrt{200,000}} + \frac{50 \times 10^{-12} \text{ s}}{1 \text{ s}} \right) \right) \times 15 \text{ MHz}$$

$$= (\pm 4.1 \times 10^{-9} \pm 2 \times (4.47 \times 10^{-12} + 50 \times 10^{-12})) \times 15 \text{ MHz}$$

$$= (\pm 4.1 \times 10^{-9} \pm 1.09 \times 10^{-10}) \times 15 \text{ MHz}$$

$$= \pm 63.1 \text{ mHz}$$

Which is to say that the Agilent 53181A would display results in the range 15 MHz ± 63.1 mHz. Note however that the dominant error is the Time Base Error. If an even higher stability time base is available to the instrument or if the instrument can be source locked to the 15 MHz signal, then this error term can be substantially reduced. The measurement resolution under these conditions is ± 0.8 mHz (1 sigma) which determines the number of digits displayed.

Chapter 3 Specifications  
Introduction

**Measurement Specifications (Continued)**

---

**Frequency Ratio:**  $\frac{1}{Ch2} / \frac{Ch2}{C}$

Measurement is specified over the full signal range of each input.

**Results Range:**  $10^{-10}$  to  $10^{11}$

**'Auto' Gate Time:** 100 ms (or sufficient cycles on Channel 1 to make a valid measurement, whichever is longer)

**LSD:**

$$\text{Ratio } 1/2 : \frac{1}{Ch2 \text{ Freq} \times \text{Gate Time}}$$

$$\text{Ratio } 2/1 : \frac{Ch2 \text{ Freq}}{(Ch1 \text{ Freq})^2 \times \text{Gate Time}}$$

**RMS Resolution:**

$$\text{Ratio } 1/2 : \frac{2 \times \sqrt{1 + (Ch1 \text{ Freq} \times Ch2 \text{ Trigger Error})^2}}{Ch2 \text{ Freq} \times \text{Gate Time}}$$

$$\text{Ratio } 2/1 : \frac{2 \times Ch2 \text{ Freq} \times \sqrt{1 + (Ch1 \text{ Freq} \times Ch2 \text{ Trigger Error})^2}}{(Ch1 \text{ Freq})^2 \times \text{Gate Time}}$$

To minimize relative phase measurement error, connect the higher frequency signal to Channel 1 when possible.

---

**Peak Volts**

Measurement is specified on Channels 1 for DC signals; or for AC signals of frequencies between 100 Hz and 30 MHz with peak-to-peak amplitude greater than 100 mV. (The measurement will continue to operate up to 225 MHz, though results are for indication only.)

**Results Range:** -5.1 V to +5.1 V

**Resolution:** 10 mV

**Systematic Uncertainty for AC signals:** 25 mV + 10% of V  
for DC signals: 25 mV + 2% of V

Use of the input attenuator multiplies all voltage specifications (input range, results range, resolution and systematic uncertainty) by a nominal factor of 10. For example with AC signals, the Systematic Uncertainty becomes: 250 mV + 10% of V.

## Chapter 3 Specifications

### Introduction

## Measurement Definitions

---

### Definitions of Systematic Uncertainty Terms

- **Trigger Error**

External source and input amplifier noise may advance or delay the trigger points that define the beginning and end of a measurement. The resulting timing uncertainty is a function of the slew rate of the signal and the amplitude of spurious noise spikes (relative to the input hysteresis band).

The (rms) trigger error associated with a single trigger point is:

$$\text{Trigger Error} = \frac{\sqrt{(E_{input})^2 + (E_{signal})^2}}{\text{Input Signal Slew Rate at Trigger Point}} \text{ (in seconds)}$$

where

$E_{input}$  = RMS noise of the input amplifier: 1 mVrms (350  $\mu$ Vrms typical). Note that the internal measurement algorithms significantly reduce the contribution of this term.

$E_{signal}$  = RMS noise of the input signal over a 225 MHz bandwidth (100 kHz bandwidth when the low-pass filter is enabled). Note that the filter may substantially degrade the signal's slew rate at the input of the trigger comparator.

- **Fractional Time Base Error**

Time base error is the maximum fractional frequency variation of the time base due to aging or fluctuations in ambient temperature or line voltage:

$$\text{Time Base Error} = \left( \frac{\Delta f}{f} \Big|_{\text{aging rate}} + \frac{\Delta f}{f} \Big|_{\text{temperature}} + \frac{\Delta f}{f} \Big|_{\text{line voltage}} \right)$$

Multiply this quantity by the measurement result to yield the absolute error for that measurement. Averaging measurements will not reduce (fractional) time base error. The Agilent 53181A counters exhibits negligible sensitivity to line voltage; consequently this term may be ignored.

---

### Typical Versus Worst Case Specifications

Specifications identified as "Typical" represent performance of the instrument that the majority of users will perceive under a wide variety of conditions and signals. The specifications identified as "Worst Case" should be used when the instrument is under extreme environmental conditions or when the accuracy of the measurement results are critically important.

## Chapter 3 Specifications

### Introduction

---

## Measurement Arming and Processing

---

### Gate Time

Auto Mode, or 1 ms to 1000 s

### Measurement Throughput

GPIB ASCII: 200 Measurements/s (maximum)  
(See examples in the Programming Guide for ways to optimize measurement throughput)

---

### Measurement Arming

**Start Measurement:** Free Run, Manual, or External  
**Stop Measurement:** Continuous, Single, External, or Timed

#### Arming Modes:

(Note: auto arming is the only mode available for the Peak Volts function.)

- Auto Arming:** Measurements are initiated immediately and acquired as fast as possible, using a minimum number of signal edges. Auto arming offers the highest measurement throughput, though measurement resolution may be reduced.
- Timed Arming:** The duration of the measurement is internally timed to a user-specified value (also known as the "gate time"). This mode should be used when the length of the measurement time must be controlled.
- Digits Arming:** Measurements are performed to the requested resolution (number of digits) through automatic selection of the acquisition time. This is the most convenient mode when a specific measurement resolution is desired.
- External Arming:** An edge on the External Arm Input enables the start of each measurement. Auto Arming, Timed arming modes or another edge on the External Arm Input may be used to complete the measurement.
- 

### Measurement Statistics

**Available Statistics:** Mean, Minimum, Maximum, Standard Deviation

**Number of Measurements:** 2 to 1,000,000. Statistics may be collected on all measurements or on only those which are between the limit bands. When the Limits function is used in conjunction with Statistics, N (number of measurements) refers to the number of in-limit measurements. In general, measurement resolution will improve in proportion to  $1/\sqrt{N}$ , up to the numerical processing limits of the instrument.

**Measurements:** Statistics may be collected for all measurements except Peak Volts.

---

### Measurement Limits

**Limit Checking:** The measurement value is checked against user-specified limits at the end of each measurement.

**Display Modes:** The measurement result may be displayed as either the traditional numeric value or graphically as an asterisk moving between two vertical bars. These bars define the upper and lower limits, and the asterisk represents the current measurement result relative to these limits.

**Out-of-Limits Indication:** The out-of-limits condition can be indicated by any of the following methods:


- The limits annunciator will light on the front panel display.
  - The instrument will generate an SRQ if enabled via GPIB.
  - The limits hardware signal provided via the RS-232 connector will go low for the duration of the out-of-limit condition (see the description of this connector under the General Information section of this specifications table).
  - If the Analog Display mode is enabled, the asterisk appears outside the vertical bars, which define the upper and lower limits.
-

## Chapter 3 Specifications

### Introduction

#### General Information

<b>Save and Recall:</b>	Up to 20 complete instrument setups may be saved and recalled later. These setups are retained when power is removed from the counter.	
<b>Rack Dimensions (HxWxD):</b>	88.5 mm x 212.6 mm x 348.3 mm	
<b>Weight:</b>	3.5 kg maximum	
	<b>AC Line Supply</b>	<b>DC Supply (Option 002 Only)</b>
<b>Power Supply Voltage:</b>	100 to 120 VAC $\pm 10\%$ - 50, 60 or 400 Hz $\pm 10\%$ 220 to 240 VAC $\pm 10\%$ - 50 or 60 Hz $\pm 10\%$ AC Line Voltage Selection: Automatic	10 to 32 VDC, 3-pin male XLR connector  Option 002 may not be ordered with Option 060
<b>Power Requirements:</b>	170 VA maximum (30 W typical)	4A initial inrush at 10 VDC 3A max, once stabilized
<b>Operating Environment:</b>	0° C to 55° C	
<b>Storage Environment:</b>	-40° C to 71° C	
<b>Remote Interface:</b>	GPIB (IEEE 488.1-1987, IEEE 488.2-1987)	
<b>GPIB Interface Capabilities:</b>	SH1, AH1, T5, TE0, L4, LE0, SR1, RL1, PP0, DC1, DT1, C0, E2	
<b>Remote Programming Language:</b>	SCPI-1992.0 (Standard Commands for Programmable Instruments)	
<b>Safety:</b>	Designed in compliance with IEC 1010-1, UL 3111-1 (draft), CAN/CSA 1010.1	
<b>EMC:</b>	CISPR-11, EN50082-1, IEC 801-2, -3, -4  Electrostatic Discharge and Fast Transient/Burst Immunity Testing: When the product is operated at maximum sensitivity (20 mVrms) and tested with 8kV AD according to IEC801-2 or with 1kV power line transients according to IEC 801-4, frequency miscounts may occur that will affect measurement data made during these disturbances.  Radiated Immunity Testing: When the product is operated at maximum sensitivity (20 mVrms) and tested at 3 V/m according to IEC 801-3, external 100 to 200 MHz electric fields may cause frequency miscounts.	
<b>RS-232C:</b>	The rear-panel RS-232 connector is a 9-pin connector (DB-9, male). You can connect the universal counter to any terminal or printer with a properly configured DTE connector (DB-25). You can use a standard interface cable (Agilent part number 24542G or 24542H). Data is "output only"; the instrument can not be programmed via the RS-232 interface.	
<b>Note on Pin 4:</b>	May be used as either a DTR signal or an indication of measurement in-limit as configured by the Utility menu. When used as an in-limit indicator, the signal will be high for every measurement within the user set limits.	



Pin Number	Type	Description
2	Input	Receive Data (RxD) (for Xon/Xoff only)
3	Output	Transmit Data (TxD)
4	Output	Data Terminal Ready (DTR) Measurement In-Limit Signal
5	—	Signal Ground
6	Input	Data Set Ready (DSR)
*	All other pins: no connection	

Chapter 3 Specifications  
**Introduction**



---

# Index

## SYMBOLS

+/- key, 1-17, 2-9

## NUMERICS

10 MHz Output connector, 1-11

100 kHz Filter key, 2-41

50W/1 MW key, 1-15, 2-41

## A

abort, 2-6

ac line selection, 1-11

accessories

available, xviii

supplied, xviii

addressed (talk/listen), 2-54

adjusting trigger level, 2-45

analog graph

limit test, 1-10

annunciators, 1-8

arming modes

auto, 2-15, 3-16

digits, 2-15, 3-16

external, 2-15, 3-16

time, 2-15, 3-16

arrow keys

entry/select keys, 2-9

Assembly-Level Service Guide, xiv

asterisk, 2-35

asterisk placeholder, 1-9

auto arming, 2-15, 3-16

Auto timebase, 2-55

auto trigger, 2-41, 2-42

auto triggering, 2-44

available options, xvii

## B

baud rate, 2-58, 2-59

## C

cables, xviii

changing the numerical convention of the display, 2-61

changing the slope, 2-45

Channel 1, 1-2, 2-41

Channel 2, 1-2, 1-5, 2-13, 2-41

characters

\*, 1-9, 1-10

limit test graph, 1-10

X, 1-9, 1-10

choosing HIGH to disable hardware

  pacing, 2-58

choosing HW PACE, 2-58

choosing the timebase source, 2-55

common questions, 2-74

computing Stats on filtered data only, 1-31

configuring the RS-232 for sending limit-detect output, 2-60

configuring the RS-232 port for printing, 2-58

connecting to a printer via GPIB, 2-62

connecting to a serial printer via the RS-232 port, 2-61

controlling measurement, 1-35

counter description, xvi

coupling, 2-47

## D

data entry keys

  numeric entry, 2-9

DC/AC key, 1-15, 2-41

definition of sensitivity, 2-42

description of

  input conditioning toggle keys, 2-47

  LIMITS keys

    Limit Modes, 2-31

    Uppr & Lower, 2-31

  Local key, 1-4

  MATH keys

    Scale & Offset key, 2-21

    Stats, 2-26

## Index

- Print menu, 2-52
- Recall menu, 2-48
- Remote indicator, 1-4
- Save menu, 2-48
- scale and offset, 1-19
- self-test routines, 2-56
- SRQ indicator, 1-4
- Trigger/Sensitivity menu key, 2-41
- Utility menu, 2-53
- description of counter, xi, xvi
- digits arming, 2-16, 3-16
- display
  - menu messages, 2-65
  - messages, 2-63
  - numerical convention
    - other countries, 2-61
    - USA, 2-61
  - power-up/self test messages, 2-64
  - SHOW
    - GRAPH, 2-34
    - NUMBER, 2-36
- Display Digits keys, 1-9
- displaying Stats after filtering data of input signal, 1-33
- DTR (Data Terminal Ready) menu, 2-58
- E**
- Enter key, 2-9
- entering numeric values, 2-9
- entering offset value, 1-20
- entry/select keys
  - arrow keys, 2-9
- equation
  - scale and offset, 1-19
- example procedure for
  - changing the number of digits of resolution, 2-19, 2-44
  - computing Stats, 2-27
  - easy viewing of Stats, 2-28
  - filtering data (using limits) during Stats, 2-29
  - Gate and External Arm, 2-17
  - Offset function, 2-23
  - running the self test, 2-57
  - Scale function, 2-22
    - setting the Offset from the last measurement value, 2-25
    - turning off Math mode, 2-25
    - turning off Stats mode, 2-30
- Example Procedure for Turning Off Math Mode, 2-25
- Ext Arm connector, 2-15, 2-17
- external 1, 5, 10 MHz reference, 2-55
- external arm, 2-17
- External Arm input connector, 1-11
- external arming, 2-15, 3-16
- external reference, 2-55
- External Reference Input connector, 1-11
- External timebase, 2-55
- F**
- fan, 1-2, 1-11
- Features and Functions
  - 100 kHz Filter (low pass filter), 2-47
  - Arming, 2-15
  - arrow keys, 2-9
  - auto timebase, 2-55
  - auto trigger, 2-41, 2-42
  - changing the number of digits of resolution displayed, 2-19
  - CHANNEL 1 input conditioning
    - keys, 2-41, 2-47
    - 100 kHz Filter (low pass filter, 2-47
    - X10 Attenuate key, 2-47
  - configuring the RS-232 port for limit-detect output, 2-60
  - configuring the RS-232 port for printing, 2-58
  - connecting to a printer via GPIB, 2-62
  - connecting to a serial printer via RS-232, 2-61
  - DISPLAY Digits keys
    - Fewer Digits, 2-39
    - More Digits, 2-39
    - underscore, 2-39
  - Enter key, 2-9
  - Entry/Select (arrow) keys, 2-9
  - External arming, 2-15

## Index

- external timebase, 2-55
  - filtering data (using limits) during
    - Stats, 2-29
  - Frequency measurements
    - channel 1, 2-12
    - channel 2, 2-12
  - Frequency Ratio measurements, 2-13
  - front-panel display messages, 2-63
  - Gate and External Arming Menu, 2-15
  - GPIB messages, 2-67
  - internal timebase, 2-55
  - Limit test analog graph, 2-35
  - Limits Menu, 2-31
  - Math Menu
    - Offset, 2-21
    - Scale, 2-21
  - measurement control keys
    - Run Key, 2-6
    - Stop/Single Key, 2-6
  - menu messages, 2-65
  - messages, 2-63
  - numerical convention, 2-61
  - Offset, 2-21, 2-23
  - ON SINGLE, 2-8
  - Peak Voltage (or Volt Peaks)
    - measurements, 2-14
  - Period measurements, 2-13
  - Preset values after power-up and \*RST, 2-68
  - Print Menu, 2-52
    - PRINT OFF/ON, 2-52
    - PRT HELP NO/YES, 2-52
  - Ratio measurements, 2-13
  - Recall, 2-48
  - Save, 2-48
  - Scale, 2-21
  - seeing digits not visible on the 12-digit display, 2-25
  - self-test routines, 2-56
  - sensitivity, 2-42, 2-44
  - SET REF, 2-25
  - slope, 2-42, 2-45
  - Statistics, 2-26
  - Stats, 2-26
  - Talk-Only, 2-62
  - timebase source selection, 2-55
  - Trigger/Sensitivity Menu, 2-41
  - Unsave, 2-51
  - Utility
    - configuring the RS-232 port, 2-58, 2-60
    - connecting to a printer, 2-62
    - connecting to a serial printer, 2-61
    - selecting the numerical convention, 2-61
    - self-tests, 2-56
    - Talk-Only, 2-62
  - Utility Menu, 2-53
    - GPIB Address, 2-54
    - timebase, 2-55
    - X10 Attenuate key, 2-47
  - Fewer Digits key, 2-39
  - Frequency, 2-11, 2-12
    - ratio, 2-13
  - front-panel indicators, 1-4
  - front-panel menus, 1-5, 1-6, 1-7
  - function
    - frequency, 2-12
    - period, 2-13
    - volt peaks, 2-14
- ## G
- Gate, 2-15
  - Gate and External Arming menu, 2-15
    - auto, 2-15
    - digits, 2-16
    - external, 2-15
    - time, 2-15
  - gate time, 2-17
  - Gate time and resolution, 2-15
  - GPIB Address, 2-54
  - GPIB connector, 1-11
  - GPIB messages, 2-67
  - GPIB to talk-only, 2-62
  - graph
    - characters, 1-10
    - limit test, 1-10

## Index

### H

- hardware pacing, 2-58
- help messages, 2-10
- how to make measurements, 1-12
- how to set limits, 1-23
- hysteresis, 2-42

### I

- impedance, 2-47
- in case of trouble, 2-74
- indicators (LEDs), 1-4
- initiating measurements, 2-6
- input conditioning keys, 2-41
- input impedance, 2-47
- internal 10 MHz oven oscillator, 2-55
- Internal timebase, 2-55

### L

- limit test graph, 1-10, 2-35
- Limit testing, 2-32
- Limit-detect output, 2-38, 2-60
- Limit-Detect Output connector, 1-11
- Limits Testing Example 1—Flag and Stop Measuring On Limits, 2-32
- Limits Testing Example 2—Flag On Limits but Continue Measuring, 2-34
- Limits Testing Example 3—Use Analog Graph Display While Adjusting Input Signal, 2-34
- Limits Testing Example 4—Selecting Filtering Conditions of Stats Computation, 2-36
- Limits Testing Example 5—Sending the Limit-Detect Output, 2-4, 2-38
- list of options, xvii
- Local key, 1-4, 2-65
- low pass filter, 2-47

### M

- making repetitive measurements, 1-35
- making the Counter flag on limits but continue measuring when the signal exceeds the user-entered limits, 1-27
- Math

- offset, 2-21
- scale, 2-21
- Math menu, 2-21
- MEASURE keys
  - Freq & Ratio, 2-11
  - Other & Meas, 2-11
  - Time & Period, 2-11
- measurement control keys, 2-6
  - Run key, 2-6
  - Stop/Single key, 2-6
- measurement function menus, 2-11
- measurement gate, 2-17
- measurement sequence, 2-5
- measuring frequency, 2-12
- measuring period, 2-13
- measuring positive/negative peaks
  - voltage, 2-14
- menu messages, 2-65
- menu roadmaps, xix
- menu tree, xix
- menus of
  - 100kHz Filter key, 1-6
  - 50 Ohm/1M Ohm key, 1-6
  - DC/AC key, 1-6
  - Freq & Ratio key, 1-5
  - Gate & ExtArm key, 1-5
  - Limit Modes key, 1-5
  - Other Meas key, 1-5
  - Recall key, 1-6
  - Save & Print key, 1-6
  - Scale & Offset key, 1-5
  - Stats key, 1-5
  - Time & Period key, 1-5
  - Trigger/Sensitivity key, 1-6
  - Upr & Lower key, 1-5
  - Utility key, 1-7
  - X10 Attenuate key, 1-6
- messages
  - front panel, 2-63
  - GPIB, 2-67
  - menu, 2-65
  - power-up/self-test, 2-64
- More Digits key, 2-39

## Index

### N

numeric entry for a menu item, 2-4  
numerical convention, 2-53, 2-61

### O

offset, 1-19, 2-21  
ON SINGLE menu item, 2-8  
options, xvii  
oscillator adjust potentiometer, 1-11  
Other Meas key, 2-13

### P

pace  
    software, 2-59  
pacing, 2-58  
parity, 2-59  
parity type, 2-58  
peak voltage, 2-11  
performing statistics on measurements, 1-29  
period, 2-11  
period measurements, 2-13  
placeholders, 1-9  
preset values, 2-68, 2-72  
presetting the Counter, 2-4  
print, 2-52  
printer  
    connect Counter to printer, 2-62  
printing, 2-52, 2-58

### Q

questions, 2-74  
quick reference guide, xii, xix

### R

ratio, 2-11, 2-13  
Ratio measurements, 2-13  
Recall function, 2-50  
recalling measurement setups, 2-48  
Ref In connector, 2-55  
related documents, xiii  
remote, 1-4  
Remote indicator (LED), 1-4  
repackaging for shipment, xv  
resetting the Counter, 2-4  
resolution, 2-15

RS-232 interface, 1-11  
RS-232 serial port, 2-38  
Run key, 2-6  
run mode, 2-6  
running the self-test routines, 2-56

### S

Save function, 2-40, 2-49  
saving measurement setups, 2-48  
Scale & Offset key, 1-19  
scale and offset equation, 1-19  
Scale and Offset functions, 2-21  
Selecting Operating Mode (Talk/Listen, Talk-Only), 2-54  
selecting sensitivity, 2-46  
selecting the type of Statistics (Stats), 1-29  
self test messages, 2-64  
self-test, 2-56  
sending limit-detect output, 2-38  
sensitivity, 1-18, 2-42  
serial port, 2-38, 2-58  
SET REF  
    , 2-25  
Setting the Baud Rate, 2-59  
Setting the Hardware Pacing, 2-58  
Setting the GPIB Address, 2-54, 2-62  
Setting the Parity, 2-59  
Setting the Software Pace, 2-59  
setting upper limit, 1-24  
sign (+/-) key, 1-17  
sign key, 2-9  
Single key, 2-6  
single mode, 2-6  
software pace, 2-59  
software pacing, 2-58  
special characters, 1-9  
specifications, 3-2  
    Agilent 53181A, 3-2  
    frequency range, 3-2  
    power supply voltage, 3-17  
    time base stability, 3-4  
SRQ indicator (LED), 1-4  
star, 1-9  
Stats function, 2-26

## Index

stop, 2-6  
summary of measurement sequence, 2-5  
SW PACE, 2-58, 2-59

### T

talk/listen, 2-54  
talk-only, 2-54, 2-62  
TEST  
    , 2-56  
time arming, 2-15, 3-16  
timebase, 2-55  
    auto, 2-55  
    external, 2-55  
    internal, 2-55  
timebase source, 2-55  
trigger band, 2-46  
trigger level, 2-45  
trigger slope, 2-45  
types of service available if your instrument fails, xiv

### U

underscore, 2-39  
underscore placeholder, 1-9  
Unsave, 2-51  
using Enter key, 2-9  
using LIMITS, 2-32  
using ON FAIL  
    GO ON menu item, 1-28  
    STOP menu item, 1-27  
using SET REF  
    , 2-25  
using SHOW  
    Stats menu item, 2-27  
using Stats key, 2-27  
using the +/- (sign) key, 1-17  
using the arrow keys  
    to change states of menu items, 2-10  
    to enter numeric values, 2-9  
    to execute prompted help messages, 2-10  
    to sequence through the menus of the  
        MEASURE keys, 2-9  
using the entry select keys  
    to enter numeric values, 2-9

using the entry/select keys  
    to change states of menu items, 2-10  
    to execute prompted help messages, 2-10  
    to sequence through the menus of the  
        MEASURE keys, 2-9  
using the Ext Arm connector, 2-17  
using the Gate & ExtArm key, 2-17  
using the input coupling toggle keys, 1-15  
using the input impedance toggle keys, 1-15  
using the Math operations  
    offset, 2-22  
    scale, 2-22  
using the measurement control keys  
    Run key, 2-7  
    Stop/Single key, 2-7  
using the Print menu, 2-52  
using the Recall function, 2-50  
using the Save function, 2-40, 2-49  
using the Scale & Offset, 2-22  
using the Scale & Offset key, 2-22  
using the Unsave function, 2-51  
Utility menu, 1-7, 2-4, 2-53

### V

volt peaks measurements, 2-14

### X

X10 Attenuate key, 2-41, 2-47