Provided by:



www.atecorp.com (800) 404-ATEC



Fusion Splicing



🚯 Bluetooth

90S+



In Work Trav



Wind Protector Open

Fujikura 90S+ Fusion Splicer

The Fujikura 90S+ core alignment fusion splicer solves common problems seen in the fieldfrom splicing poor quality legacy fiber to automated equipment maintenance and upkeep. The Fujikura 90S+ can be use in multiple field splicing applications including bend-insensitive fibers in drop cables, long-haul terrestrial and submarine LEAF® fibers, loose buffer fiber, splice-on connectors, and the list goes on. The speed and accuracy of the 90S+ make it suitable for certain production and specialty environments where high output, tight packaging, and low loss requirements are required.

Regardless of your scenario, the Fujikura 90S+ is designed to keep you in the field with an extended battery life of 300 splice and heat cycles. With its multiple automated and easy-touse features, the 90S+ alleviates the need for traditional operation tasks such as frequent arc calibrations, cleaver blade rotations, cleaver usage tracking, and manual splicing operations. A redesigned work tray, cooling tray, and optional cable clamp make the 90S+ kit more versatile than its predecessors in adapting to varying work conditions and environments.

When splicing loose buffer fiber, additional sheath clamps are not needed. The standard universal sheath clamp now handles both loose and tight buffer fibers. The new Active Fusion Control (AFC) technology improves splice losses for fibers that possess a poor cleave angle. Combined with Active Blade Management between the splicer and cleaver, the Fujikura 90S+ contains a robust set of splicing features that will reduce the likelihood of poor splice installations or repairs.

Features

- Cleaver tracking and upkeep with wireless communication
- Improved real-time arc control for fibers with poor cleave angles
- Automated wind protector, sheath clamps and splice operation
- Loose and tight buffer with same sheath clamp
- Lithium-ion battery with 300 splices/shrinks per charge
- PC software and 90S+ manual downloaded from splicer
- Multi-function transit case with integrated workstation

Applications

- Distribution fiber repair
- Long-haul network installation
- Field termination with splice-on connectors
- Access network installation
- Fanout kits, pigtails and splice cassettes
- OSP cable installation and repair
- Optical modules splitters, couplers, MUXs, EDFAs and attenuators





Fujikura 90S+ Fusion Splicer

Ordering Information

DESCRIPTION	AFL NO.
90S+ Fusion Splicer (machine only) Includes: Includes: ADC-20 AC Adapter, ACC-14 AC Cord, BTR-15 Battery, ELCT2-16B Spare Electrodes (pair), Sheath Clamps, SP-03 Fiber Holder Set Plates, USB-01 Cable, Alcohol Dispenser, Screwdriver, Splicer Carrying Strap, Quick Reference Guide, TS-03 Tripod Screw, Work Tray J-Plate, SS03 single fiber stripper, CC39 Transit Case with Carrying Strap and Two Year Warranty	S017519
90S+ Fusion Splicer Kit (with cleaver) Includes: CT50 Cleaver, ADC-20 AC Adapter, ACC-14 AC Cord, BTR-15 Battery, ELCT2-16B Spare Electrodes (pair), Sheath Clamps, SP-03 Fiber Holder Set Plates, USB-01 Cable, Alcohol Dispenser, Screwdriver, Splicer Carrying Strap, Quick Reference Guide, TS-03 Tripod Screw, Work Tray J-Plate, SS03 single fiber stripper, CC39 Transit Case with Carrying Strap and Two Year Warranty	S017521
90S+ Fusion Splicer without Bluetooth (machine only) Includes: ADC-20 AC Adapter, BTR-15 Battery, ACC-14 AC Cord, ELCT2-16B Spare Electrodes (pair), Sheath Clamps, SP-03 Fiber Holder Set Plates, USB-01 Cable, Alcohol Dispenser, Screwdriver, Splicer Carrying Strap, Quick Reference Guide, TS-03 Tripod Screw, Work Tray J-Plate, SS03 Single Fiber Stripper, CC39 Transit Case with Carrying Strap and Two Year Warranty	S017520
One Year Extended Warranty	S012996
Two Year Extended Warranty	S013000

Recommended Products for the 90S+

DESCRIPTION	AFL NO.
Cleavers	
CT08 Cleaver	S017004
CT50 Cleaver	S017030
Fiber Holders (pair)	
FH-70-250 (250 µm coated fiber)	S017111
FH-70-900 (900 µm jacketed fiber)	S017113
FH-70-160 (160 µm coated fiber)	S017095
FH-70-200 (200 µm coated fiber)	S017711
FH-60-LT900 (Loose buffer 900 µm fiber)	S015181
FUSEConnect [®] Accessories	
FH-FC-20 (900 µm within 2.0 mm sheathing) (each)	S014696
FH-FC-30 (900 µm within 3.0 mm sheathing) (pair)	S014695
FH-FC-900 (900 µm cable) (each)	S014697
CLAMP-FC-2000 (pair)	S014705
CLAMP-FC-3000 (pair)	S014704
Power Supply Options and Equipment	
ADC-20 AC Adapter	S017513
ACC-14 AC Power Cord	S014536
BTR-15 Battery	S017512
DCC-20 Power Cord (connects AC Adapter to cigarette lighter socket)	S017527

DCC-21 Power Cord	S017528
(connects AC Adapter to power source via alligator clips)	
DESCRIPTION	AFL NO.
Miscellaneous	
SS03 Single fiber stripper (3 hole)	S017098
SS01 Single fiber stripper (1 hole)	S017099
ELCT2-16B Electrodes	S017103
SP-03 Fiber Holder Set Plates	S017518
S90 Universal Sheath Clamps	S017696
Portable Tripod Workstation (see product profile for more detail)	S014773
ASW-02 Splicing Workstation (see product profile for more detail)	S010532
WT-09R Work Tray Right	S017515
WT-09L Work Tray Left	S017516
JP-09 Work Tray J-Plate	S017517
JP-10 J-Plate (Cooling tray attaches to splicer)	S017522
JP-10-FC J-Plate with Fiber Clamps	S017523
TS-03 Tripod Screw (90 Series)	S017524
ST-02 Fusion Splicer Strap	S017525
CLAMP-DC-12 (Drop cable clamp for work tray)	S017550
USB-01 Cable	S014777



Fiber Holders

• Wide range of sizes for various applications

• Loose & Tight Buffer options available

Portal Tripod Work Station

- Sturdy work tray supports the splicer, cleaver and accessories
- Tripod supports a load capacity of up to eleven pounds

V-Groove Cleaning Kit

- Removes environmental contamination from
 the v graceve of the colicer
- the v-groove of the splicer
- Maintains performance and ensures fiber alignment



Fujikura 90S+ Fusion Splicer

Specifications

PARAMETER		VALUE
Fiber Alignment Method		Active core alignment
Fiber Count Can Be Spliced		Single fiber
	Fiber Type	Single mode optical fiber
Applicable Fiber		Multi mode optical fiber
	Cladding Dia.	80 to 150 µm
		Coating dia. : Max. 3,000 µm
Applicable Coating	Sheath Clamp	
	· · · · · ·····	Cleave length : 5 to 16 mm
		ITU-T G.652 : Avg. 0.02 dB
		ITU-T G.651 : Avg. 0.01 dB
Fiber Splice Performance Applicable Protection Sleeve	Splice Loss	ITU-T G.653 : Avg. 0.04 dB
		ITU-T G.654 : Avg. 0.04 dB
		ITU-T G.655 : Avg. 0.04 dB
		ITU-T G.657 : Avg. 0.02 dB
		SM FAST mode : Avg. 8 to 10 sec.
	Splice Loss	SM AUTO mode : Avg. 11 to 13 sec.
		AUTO mode : Avg. 14 to 16 sec.
	Sleeve Type	Heat-shrinkable sleeve
	Sleeve Length	Max. 66 mm
	Sleeve Dia.	Max. 6.0 mm before shrinking
		60 mm slim mode : Avg. 9 to 10 sec.
leeve Heat Performance	Heat Time	60 mm mode : Avg. 13 to 15 sec.
The sector sile Test Course		
iber Tensile Test Force		Approx. 2.0 N
Electrode Life		Approx. 5,000 splices
	Dimensions W	Approx.170 mm without projection
Physical Description	Dimensions D	Approx.173 mm without projection
nysical Description	Dimensions H	Approx.150 mm without projection
	Weight	Approx. 2.8 kg including battery
	- ·	Operate : -10 to 50°C
	Temperature	Storage : -40 to 80°C
Environmental Condition		Operate : 0 to 95% RH non-condensing
	Humidity	Storage : 0 to 95% RH non-condensing
	Altitude	Max. 5,000 m
Ac Adaptor	Input	
Ac Adaptor		AC100 to 240 V, 50/60 Hz, Max. 1.5 A
	Туре	Rechargeable Lithium Ion
	Output	Approx. DC14.4V / 6,380 mAh
	Capacity	Approx. 300 splice and heat cycles
Battery Pack	Temperature	Recharge : 0 to 30°C
	Temperature	Storage : -20 to 30°C
	Battery Life	Approx. 500 recharge cycles
	Recharge Time	Approx. 5 – 8 hours from empty
2:	LCD Monitor	TFT 5 inches with touch screen
Display	Magnification	200 to 320x
llumination	V-Grooves	LED lamp
	PC	USB2.0 Mini B type
	External Led Lamp	USB2.0 A type, Approx. DC5V, 500 mA
nterface	Ribbon Stripper	Mini DIN 6 pin, DC12V, Max. 1A
	Wireless	Bluetooth 4.1 LE
	Splice Mode	100 splice modes
Data Storage	Heat Mode	30 heat modes
	Splice Result	20,000 splices
	Splice Image	100 images
crew Hole For Tripod		1/4-20 UNC
		Splice mode select by fiber type analysis
	Automatic Functions	Discharge power calibration
		Wind protector : open/close
		Sheath clamp : open
Other Features		Heater lid : open/close
		Heater clamp : open/close
	Deference Cuide	
	Reference Guide	Video and PDF file stored in splicer
	Sheath Clamp Electrode	Easy sleeve positioning clamp Replaceable without tool