

**SOLA-2654-2-ACCY01**  
 Accessory Kit

Part #	Description	Qty	
SOLA-2654-2-MAN01	User's Manual for 2654-2	1	
GENE-PC-5-15A	Power Cord 120V 15A	1	
SOLA-2654-2-SW01	Control Software CD for 2654-2	1	
GENE-USB	USB Cable, Type A to Type B, 6'	1	
SOLA-2654-1/FD	Waveform 1 (Cable Bundle) & 5A (Pin Injection) Driver Module for 2654-2	1	
SOLA-2654-B	Waveform 2 (Cable Bundle) Driver Module for 2654-2	1	




**SOLA-2654-2-ACCY01**  
Accessory Kit

Part #	Description	Qty	
SOLA-2654-C	Waveform 3A (Pin Injection & Cable Bundle) Driver Module for 2654-2	1	
SOLA-2654-D	Waveform 3B (Cable Bundle) Driver Module for 2654-2	1	
SOLA-2654-1/ED	Waveform 4 (Cable Bundle, Pin Injection & Gnd Injection) Driver Module for 2654-2	1	
SOLA-2654-R	Blank Module for 2654-2	1	
SOLA-2654-1/AEC	Waveform 1 (Cable Bundle) External Module for 2654-2	1	
SOLA-2654-1/EEC1/2	Waveform 4 (Cable Bundle) External Module for 2654-2	1	



**SOLA-2654-2-ACCY01**  
Accessory Kit

Part #	Description	Qty	
SOLA-2654-1/EEC3	Waveform 4 (Cable Bundle L3) External Module for 2654-2	1	
SOLA-2654-1/EEP	Waveform 4 (Pin Injection) External Module for 2654-2	1	
SOLA-2654-1/FEP	Waveform 5A (Pin Injection) External Module for 2654-2	1	
SOLA-2654-1/EEG	Waveform 4 (Ground Injection) External Module for 2654-2	1	
SOLA-2654-1/FDG	Waveform 5A (Ground Injection) Driver Module for 2654-2	1	
SOLA-2654-1/FEG	Waveform 5A (Ground Injection) External Module for 2654-2	1	



**SOLA-2654-2-ACCY01**  
Accessory Kit

Part #	Description	Qty	
SOLA-2115-1	Conditioning Network for Waveform 3B of 2654-2 (BNC in/Out)	1	
SOLA-2809-1-NR	0.02 V/A Resistive Current Monitor Loop for 9616 (and 2654-1)	1	
SOLA-2903-1	25ohm Series Resistor for Waveform (Pin Injection) of 2654-2	1	
SOLA-2904-1	25ohm Verification Resistor for Waveform 3A (Pin Injection) of 2654-2	1	
SOLA-2905-1	5ohm Verification Resistor for Waveform 4 (Pin Injection) of 2654-2	1	
SOLA-2906-1	1ohm Verification Resistor for Waveform 5A (Pin Injection) of 2654-2	1	



**SOLA-2654-2-ACCY01**  
Accessory Kit

Part #	Description	Qty	
SOLA-9616-2-NR	DO-160 Waveform 4 Injection Clamp	2	
SOLA-9719-1N-NR	10kHz-350MHz Injection Probe 200W max	1	
SOLA-9127-1-NR	1kHz-100MHz Current Injection Probe, 200W Max	1	
SOLA-2816-1	Probe Header Interface for 9616-1/9616-2	1	
SOLA-9915-1	Clamp Interconnect for 9916-1/9916-2 (connects 2 together)	1	
SOLA-9916-1	Clamp Windings Jumpers 9916-1/9916-2	4	





**SOLA-2654-2-ACCY01**  
Accessory Kit

Part #	Description	Qty	
SOLA-2806-1M	1m RG214/U Dual Banana to Dual Banana Cable	1	
SOLA-2806-1BN	1m RG214/U Type N(m) to Dual Banana Cable	1	
SOLA-2915-1	Injection Clamp for Waveform 2, Level 1 of 2654-2	1	
SOLA-2915-2	Injection Clamp for Waveform 2 Level 2 of 2654-2	1	
PAST-PE3062-36	N(m)-N(m) Cable RG214, 36"	1	
PAST-PE9005	Adapter, BNC(m)-N(f)	1	



**SOLA-2654-2-ACCY01**  
Accessory Kit

Part #	Description	Qty	
POMO-1269	Adapter, Dual Banana(m) to BNC(f)	1	
SOLA-2902-1	Current Sensing Resistor 0.02ohm for Waveform 5A (Gnd Injection) 2654-2	1	
SOLA-9127-1-MAN01	Manual for the SOLA 9127-1	1	
SOLA-2925-1-MAN01	Instruction Manual for the SOLA-2925-1 Calibration Fixture	1	
SOLA-9719-1N-MAN01	Instruction manual	1	
SOLA-2925-1-NR	20Hz-100MHz Injection Probe Cal Fixture, Type N(f)	1	



**SOLA-2654-2-ACCY01**  
Accessory Kit

Part #	Description	Qty	
SOLA-9616-2-MAN01	Instruction Manual for SOLA-9616-2	2	