















**SCHA-CDN3063-ACCY01**  
Accessory Kit

Part #	Description	Qty	
GENE-PC-5-15A	Power Cord 120V 15A	1	
SCHA-NSG3060-CABLE03	Ground Cable w/ Thumb Screw	1	
SCHA-NSG3060-CABLE01	Surge Cable 40cm, Fischer (m) to (m)	2	
SCHA-CDN3063-601-315D	User Manual for the CDN-3063	1	
SCHA-NSG3060-CABLE05	System Cable, DB-25 (m) to (f)	1	
SCHA-403-888	Allen Key, 4mm for CDN3063-S32	1	



**SCHA-CDN3063-C32-ACCY01**  
Accessory Kit

Part #	Description	Qty	
GENE-PC-5-15A	Power Cord 120V 15A	1	
SCHA-CDN3063-601-315C	User Manual for the CDN-3063	1	
SCHA-NSG3060-CABLE01	Surge Cable 40cm, Fishcer (m) to (m)	2	
SCHA-NSG3060-CABLE03	Ground Cable w/Thumb Screw	1	
SCHA-NSG3060-CABLE05	System Cable, DB-25 (m) to (f)	1	
SCHA-403-888	Allen key, 4mm for CDN3063-C32	1	



**SCHA-CDN3063-C32-ACCY01**  
Accessory Kit

Part #	Description	Qty	
SCHA-NSG3060-CABLE02	Burst Cable 45cm, SHV (m) to (m)	1	