









FLUK-1550B-ACCY01
Accessory Kit

Part #	Description	Qty	
FLUK-1550B-CASE01	Soft Carry Case with Straps	1	
FLUK-1642639	Test Clip- Green	1	
FLUK-1642621	Test Clip- Black	1	
FLUK-1642617	Test Clip- Red	1	
FLUK-1642600	Test Lead- Green	1	
FLUK-1642591	Test Lead- Black	1	





FLUK-1550B-ACCY01
Accessory Kit

Part #	Description	Qty	
FLUK-1642584	Test Lead- Red	1	
FLUK-1578406	Optical to USB Cable Assembly	1	
FLUK-2076262	Installation Guide for Flukeview Forms	1	
FLUK-2395928	Installation Guide for USB-IR/RS232 Cable	1	
FLUK-2099943	Quick Reference Guide for FLUK-1550B	1	
FLUK-3001289	User Manual for FLUK-1550B	1	



FLUK-1550B-ACCY01
Accessory Kit

Part #	Description	Qty	
FLUK-1550B-SW01	FlukeView Forms Basic, CD	1	
FLUK-2099928	Manual Set on CD for FLUK-1550B	1	
GENE-PC-5-15A	Power Cord 120V 15A	1	