



FUJI-FSM-70S-PKG01-ACCY01
Accessory Kit

Part #	Description	Qty	
FUJI-CT30	Cleaver with Case and Instructions	1	
FUJI-Q-19/70S-E	Quick Reference Guide for FSM-70S	1	
GENE-PC-5-15A	Power Cord 120V 15A	1	
FUJI-DCC-18	Cable, Battery Charger	1	
FUJI-BTR-09	Battery Pack	1	
FUJI-SL-01	Sleeve Loader	1	



FUJI-FSM-70S-PKG01-ACCY01
Accessory Kit

Part #	Description	Qty	
FUJI-USB-01	USB Cable, A to Mini B	1	
FUJI-M-70	Instruction Manual for FSM-70S (Paper or CD)	1	
FUJI-W-70-E	Warning and Caution Sheet	1	
FUJI-CC-30	Hard Carry Case with Strap	1	
FUJI-ADC-18	AC Adapter/Battery Charger	1	
CLEA-CT811	Optical Cleaning Pad	5	



FUJI-FSM-70S-PKG01-ACCY01
Accessory Kit

Part #	Description	Qty	
FUJI-FSM-70S-WT01	Work Tray	1	