












FLUK-OPTVIEW-ACCY01
Accessory Kit

Part #	Description	Qty	
FLUK-OV-CASE01	Soft Carry Case with Strap for Fluke Optiview	1	
FLUK-LC8	Line Cord for Fluke Optiview	1	
FLUK-1626397	Software, Optiview Resource CD	1	
FLUK-1567629	Cable ID for Fluke Optiview	1	
FLUK-1560817	Getting Started Guide for Fluke Optiview	1	
FLUK-1560798	Quick Reference Guide for Fluke Optiview	1	



FLUK-OPTIVIEW-ACCY01
Accessory Kit

Part #	Description	Qty	
FLUK-1280434	Battery, External for Fluke Optiview (installed)	1	
FLUK-1565193	Power Supply for Fluke Optiview	1	
FLUK-1560800	Start Up Card for Fluke Optiview	1	
FLUK-1279398	Stylus for Fluke Optiview	1	